

## ProtectToolkit 5.9.1 ProtectServer HSM

### PSESH COMMAND REFERENCE GUIDE



## Document Information

Last Updated	2024-04-18 12:26:17-04:00
--------------	---------------------------

### Trademarks, Copyrights, and Third-Party Software

Copyright 2009-2024 Thales Group. All rights reserved. Thales and the Thales logo are trademarks and service marks of Thales Group and/or its subsidiaries and are registered in certain countries. All other trademarks and service marks, whether registered or not in specific countries, are the property of their respective owners.

### Disclaimer

All information herein is either public information or is the property of and owned solely by Thales Group and/or its subsidiaries who shall have and keep the sole right to file patent applications or any other kind of intellectual property protection in connection with such information.

Nothing herein shall be construed as implying or granting to you any rights, by license, grant or otherwise, under any intellectual and/or industrial property rights of or concerning any of Thales Group's information.

This document can be used for informational, non-commercial, internal, and personal use only provided that:

- > The copyright notice, the confidentiality and proprietary legend and this full warning notice appear in all copies.
- > This document shall not be posted on any publicly accessible network computer or broadcast in any media, and no modification of any part of this document shall be made.

Use for any other purpose is expressly prohibited and may result in severe civil and criminal liabilities.

The information contained in this document is provided "AS IS" without any warranty of any kind. Unless otherwise expressly agreed in writing, Thales Group makes no warranty as to the value or accuracy of information contained herein.

The document could include technical inaccuracies or typographical errors. Changes are periodically added to the information herein. Furthermore, Thales reserves the right to make any change or improvement in the specifications data, information, and the like described herein, at any time.

Thales Group hereby disclaims all warranties and conditions with regard to the information contained herein, including all implied warranties of merchantability, fitness for a particular purpose, title and non-infringement. In no event shall Thales Group be liable, whether in contract, tort or otherwise, for any indirect, special or consequential damages or any damages whatsoever including but not limited to damages resulting from loss of use, data, profits, revenues, or customers, arising out of or in connection with the use or performance of information contained in this document.

Thales Group does not and shall not warrant that this product will be resistant to all possible attacks and shall not incur, and disclaims, any liability in this respect. Even if each product is compliant with current security standards in force on the date of their design, security mechanisms' resistance necessarily evolves according to the state of the art in security and notably under the emergence of new attacks. Under no circumstances, shall Thales Group be held liable for any third party actions and in particular in case of any successful attack against systems or equipment incorporating Thales products. Thales Group disclaims any liability with respect to security for direct, indirect, incidental or consequential damages that result from any use of its products. It is further stressed

that independent testing and verification by the person using the product is particularly encouraged, especially in any application in which defective, incorrect or insecure functioning could result in damage to persons or property, denial of service, or loss of privacy.

All intellectual property is protected by copyright. All trademarks and product names used or referred to are the copyright of their respective owners. No part of this document may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, chemical, photocopy, recording or otherwise without the prior written permission of Thales Group.

# CONTENTS

Preface: About the PSESH Command Reference Guide .....	7
Document Conventions .....	7
Support Contacts .....	9
<b>Chapter 1: Using PSESH .....</b>	<b>10</b>
Users .....	10
Features .....	11
Accessing PSESH .....	11
Admin Account Lockout and Recovery .....	12
<b>Chapter 2: PSESH Commands .....</b>	<b>13</b>
audit .....	15
audit audit .....	16
audit audit changepwd .....	17
audit audit init .....	18
audit audit secret .....	19
audit log .....	20
audit log clear .....	21
audit log rotation .....	22
audit log show .....	23
audit service .....	24
audit service disable .....	25
audit service enable .....	26
exit .....	27
files .....	28
files clear .....	29
files delete .....	30
files show .....	31
help .....	32
hsm .....	33
hsm reset .....	34
hsm show .....	35
hsm state .....	36
network .....	37
network dns .....	38
network dns add .....	39
network dns add nameserver .....	40
network dns add searchdomain .....	41
network dns delete .....	42
network dns delete nameserver .....	43

network dns delete searchdomain .....	44
network domain .....	45
network hostname .....	46
network interface .....	47
network interface bonding .....	48
network interface bonding config .....	49
network interface bonding disable .....	52
network interface bonding enable .....	53
network interface bonding show .....	54
network interface delete .....	55
network interface dhcp .....	56
network interface static .....	57
network interface ipv6 .....	59
network iptables .....	60
network iptables addrule .....	61
network iptables addrule accept .....	62
network iptables addrule accept host .....	63
network iptables addrule accept network .....	64
network iptables addrule drop .....	65
network iptables addrule drop host .....	66
network iptables addrule drop network .....	67
network iptables clear .....	68
network iptables delrule .....	69
network iptables save .....	70
network iptables show .....	71
network ping .....	72
network route .....	73
network route add .....	74
network route clear .....	75
network route delete .....	76
network route show .....	77
network show .....	78
package .....	79
package list .....	80
package list all .....	81
package list ptk .....	82
package install .....	83
package listfile .....	84
service .....	85
service list .....	86
service restart .....	87
service start .....	88
service status .....	89
service stop .....	90
status .....	91
status cpu .....	93
status date .....	94

status disk .....	95
status interface .....	96
status mac .....	97
status mem .....	98
status netstat .....	99
status ps .....	100
status time .....	102
status zone .....	103
sysconf .....	104
sysconf appliance .....	105
sysconf appliance factory .....	106
sysconf appliance poweroff .....	107
sysconf appliance reboot .....	108
sysconf etnetcfg .....	109
sysconf etnetcfg set .....	110
sysconf etnetcfg show .....	111
sysconf snmp .....	112
sysconf snmp config .....	113
sysconf snmp disable .....	114
sysconf snmp enable .....	115
sysconf snmp show .....	116
sysconf time .....	117
sysconf timezone .....	118
sysconf timezone set .....	119
sysconf timezone show .....	120
syslog .....	121
syslog cleanup .....	123
syslog export .....	124
syslog period .....	125
syslog remotehost .....	126
syslog remotehost add .....	127
syslog remotehost clear .....	128
syslog remotehost delete .....	129
syslog remotehost list .....	130
syslog rotate .....	131
syslog rotations .....	132
syslog show .....	133
syslog tail .....	135
syslog tarlogs .....	136
user password .....	137
<b>Glossary .....</b>	<b>139</b>

# PREFACE: About the PSESH Command Reference Guide

This document describes how to access and use the PSESH command line interface. It contains the following chapters:

- > ["Using PSESH" on page 10](#)
- > ["PSESH Commands" on page 13](#)

This preface also includes the following information about this document:

- > ["Document Conventions" below](#)
- > ["Support Contacts" on page 9](#)

For information regarding the document status and revision history, see ["Document Information" on page 2](#).

## Document Conventions

---

This document uses standard conventions for describing the user interface and for alerting you to important information.

### Notes

Notes are used to alert you to important or helpful information. They use the following format:

**NOTE** Take note. Contains important or helpful information.

### Cautions

Cautions are used to alert you to important information that may help prevent unexpected results or data loss. They use the following format:

**CAUTION!** Exercise caution. Contains important information that may help prevent unexpected results or data loss.

### Warnings

Warnings are used to alert you to the potential for catastrophic data loss or personal injury. They use the following format:

**\*\*WARNING\*\*** Be extremely careful and obey all safety and security measures. In this situation you might do something that could result in catastrophic data loss or personal injury.

## Command Syntax and Typeface Conventions

Format	Convention
<b>bold</b>	<p>The bold attribute is used to indicate the following:</p> <ul style="list-style-type: none"> <li>&gt; Command-line commands and options (Type <b>dir /p</b>.)</li> <li>&gt; Button names (Click <b>Save As</b>.)</li> <li>&gt; Check box and radio button names (Select the <b>Print Duplex</b> check box.)</li> <li>&gt; Dialog box titles (On the <b>Protect Document</b> dialog box, click <b>Yes</b>.)</li> <li>&gt; Field names (<b>User Name</b>: Enter the name of the user.)</li> <li>&gt; Menu names (On the <b>File</b> menu, click <b>Save</b>.) (Click <b>Menu &gt; Go To &gt; Folders</b>.)</li> <li>&gt; User input (In the <b>Date</b> box, type <b>April 1</b>.)</li> </ul>
<i>italics</i>	In type, the italic attribute is used for emphasis or cross-references to other documents in this documentation set.
<variable>	In command descriptions, angle brackets represent variables. You must substitute a value for command line arguments that are enclosed in angle brackets.
[ <b>optional</b> ] [<optional>]	Represent optional <b>keywords</b> or <variables> in a command line description. Optionally enter the keyword or <variable> that is enclosed in square brackets, if it is necessary or desirable to complete the task.
{ <b>a b c</b> } {<a> <b> <c>}	Represent required alternate <b>keywords</b> or <variables> in a command line description. You must choose one command line argument enclosed within the braces. Choices are separated by vertical (OR) bars.
[ <b>a b c</b> ] [<a> <b> <c>]	Represent optional alternate keywords or variables in a command line description. Choose one command line argument enclosed within the braces, if desired. Choices are separated by vertical (OR) bars.



## Support Contacts

---

If you encounter a problem while installing, registering, or operating this product, please refer to the documentation before contacting support. If you cannot resolve the issue, contact your supplier or [Thales Customer Support](#).

Thales Customer Support operates 24 hours a day, 7 days a week. Your level of access to this service is governed by the support plan arrangements made between Thales and your organization. Please consult this support plan for further information about your entitlements, including the hours when telephone support is available to you.

### Customer Support Portal

The Customer Support Portal, at <https://supportportal.thalesgroup.com>, is where you can find solutions for most common problems. The Customer Support Portal is a comprehensive, fully searchable database of support resources, including software and firmware downloads, release notes listing known problems and workarounds, a knowledge base, FAQs, product documentation, technical notes, and more. You can also use the portal to create and manage support cases.

**NOTE** You require an account to access the Customer Support Portal. To create a new account, go to the portal and click on the **REGISTER** link.

### Telephone

The support portal also lists telephone numbers for voice contact ([Contact Us](#)).

# CHAPTER 1: Using PSESH

The PSESH shell command line tool provides access to the ProtectServer Network HSM shell for performing basic appliance configuration tasks such as network configuration and appliance software package updates and management.

PSESH commands are not case sensitive.

Access to PSESH is via SSH or the local console.

This chapter contains the following sections:

- > ["Users" below](#)
- > ["Features" on the next page](#)
- > ["Accessing PSESH" on the next page](#)
  - ["Admin Account Lockout and Recovery" on page 12](#)

## Users

The following users can access PSESH:

User	Description
<b>admin</b>	The <b>admin</b> user is responsible for managing the appliance. The <b>admin</b> user is able to execute all of the PSESH commands available to the <b>pseoperator</b> , as well as commands used to perform package upgrades/installations, troubleshooting, viewing log files, and extracting log files. The <b>admin</b> user is also able to reset the password for the <b>audit</b> and <b>pseoperator</b> users.
<b>audit</b>	The <b>audit</b> user is responsible for managing logging on the appliance. The audit user is able to execute the PSESH commands used to manage audit logging configuration, log rotation scheduling, and settings for the <b>audit</b> user role.
<b>pseoperator</b>	The <b>pseoperator</b> user is responsible for configuring the appliance for client access. The <b>pseoperator</b> user is able to execute the PSESH commands used to configure the appliance network parameters such as IP addresses, iptables, and routes etc., as well as appliance settings such as the date/time, SNMP configuration, etc.

## Features

PSESH provides the following features:

Feature	Description
Command history	You can scroll through the commands you have entered on the PSESH command line using the up/down arrows keys.
Console history	You can scroll up to see the console history with SHIFT+PageUp.
Command shortcuts	You must type sufficient letters of a command or sub-command to make the input unique in the current syntax. For example, you could invoke system syntax help with <b>help</b> , <b>hel</b> , <b>he</b> , but not just <b>h</b> (because there is also an <b>hsm</b> command and typing just " <b>h</b> " is not sufficient to indicate whether you want <b>help</b> or <b>hsm</b> ).
Command completion	You can use the TAB key to automatically complete partially typed commands. This allows you to type only enough characters to uniquely identify the command, and then press TAB to automatically fill in the rest of the characters for the command.
Command syntax help	To display help information for a command, type <b>help</b> <command_name>, or ? <command_name>.

## Accessing PSESH

You can access PSESH by connecting a keyboard and monitor to the appliance, using a serial connection, or using an SSH client (such as puTTY in Windows or the **ssh** command in Linux) after the network settings have been configured.

### To access PSESH

1. Connect to the appliance (monitor and keyboard, serial connection, or SSH).  
When a successful connection is made, a terminal window opens and the prompt **login as:** appears.  
You can log in as **admin**, **pseoperator**, or **audit** (see "[Users](#)" on the previous page for details on these roles).
2. You are prompted for the password. If this is the first time you have signed in as this user, the default password is **password**. You will be prompted to enter a new password.  
Once you have logged in, the system presents the **psesh:>** prompt, includes the hostname you assigned to the appliance:

```
[myPSE] psesh:>
```

**NOTE** After three failed SSH login attempts, the account will be locked out for 10 minutes.

You can now issue any PSESH command. For a summary, type **?** or **help** and press **Enter**.

## Admin Account Lockout and Recovery

As a security measure, the **admin** account is locked out after 10 consecutive failed login attempts using the console (serial port or keyboard and monitor). Further login attempts will produce a message like the following:

```
Your admin account is locked due to 11 failed logins.
You will need to tamper the HSM and reboot the system to reset the admin password.
```

**CAUTION!** Tampering the HSM will destroy all tokens and stored objects. Back up any important cryptographic objects using the ProtectToolkit client software before you proceed.

### To recover the admin account

1. Tamper the HSM by turning the tamper lock key or pressing the tamper switch. See [Tampering or Decommissioning the HSM](#) in the "Operational Tasks" section of the *ProtectToolkit-C Administration Guide*.
2. Reboot the appliance using one of the following methods:
  - Log in to PSESH as **pseoperator** and run **sysconf appliance reboot**.
  - Hard reboot
    - ProtectServer External 2
 

Press the recessed reset button on the appliance's front panel See [Reset button](#) in the "ProtectServer External 2 Installation and Configuration" section of the *ProtectServer HSM and ProtectToolkit Installation Guide*.
    - ProtectServer External 2 Plus
 

Press the start/stop switch on the appliance's rear panel. See [ProtectServer External 2 Plus rear panel](#) in the "ProtectServer External 2 Plus Installation and Configuration" section of the *ProtectServer HSM and ProtectToolkit Installation Guide*.

Wait at least 15 seconds, and press the start/stop switch again to restart the system.

After a successful reboot, the following message is displayed, followed by the login prompt:

```
Protect Server External II v5.9.1
```

```
Warning: This is a password recovery process.
         The HSM is tampered and rebooted after max password retry failures.
         The admin password is reset to factory default now.
         You are required to change the password at the first login.
```

```
myPSE login:
```

3. Log in to the unlocked **admin** account using the default password ("**password**"). You are prompted to set a new password for the **admin** account.
4. Set a new **admin** password.
5. The password recovery process halts the SSH service on the appliance. Restart the SSH service with the following command:

```
psesh:>service restart ssh
```

# CHAPTER 2: PSESH Commands

This chapter describes how to access and use the PSESH shell command line tool to configure your ProtectServer Network HSM appliances.

The commands are presented alphabetically and provide:

- > a brief description of the command function
- > the command syntax and parameter descriptions
- > usage examples.

The top-level commands are as follows:

Argument(s)	Description
<b>audit</b>	Manage HSM auditing tasks. Only available to the <b>audit</b> user. See <a href="#">"audit" on page 15</a> .
<b>exit</b>	Exit the PSESH shell. See <a href="#">"exit" on page 27</a> .
<b>files</b>	Manage the files that have been transferred to the appliance's SCP directory. See <a href="#">"files" on page 28</a> .
<b>help</b>	Display syntax help for the specified command. You can use the <b>?</b> symbol instead of the string <b>help</b> as an alternative way of displaying the help. See <a href="#">"help" on page 32</a> .
<b>hsm</b>	Display the current state of the HSM, or reset the HSM if it becomes unresponsive. See <a href="#">"hsm" on page 33</a> .
<b>network</b>	View or configure the network settings for the ProtectServer Network HSM appliance. See <a href="#">"network" on page 37</a> .
<b>package</b>	Manage the software packages installed on the appliance. See <a href="#">"package" on page 79</a> .
<b>service</b>	Manage the services on the appliance. See <a href="#">"service" on page 85</a> .
<b>status</b>	Display the current status of the appliance. See <a href="#">"status" on page 91</a> .
<b>sysconf</b>	Configure the appliance time, date, or SNMP settings, or reboot or power-off the appliance. See <a href="#">"sysconf" on page 104</a> .
<b>syslog</b>	Display or archive the syslog. See <a href="#">"syslog" on page 121</a> .

---

Argument(s)	Description
<b>user</b>	Set or change the password of the current user. See " <a href="#">user password</a> " on <a href="#">page 137</a> .

---

# audit

Manage HSM auditing tasks, including audit logging configuration, log rotation scheduling, and settings for the **audit** user role.

## User access

### audit

The **audit** appliance role also has access to the ["user password" on page 137](#) and ["syslog tarlogs" on page 136](#) command.

## Syntax

### audit

**audit**  
**log**  
**service**

Argument(s)	Shortcut	Description
<b>audit</b>	<b>a</b>	Manage <b>audit</b> user role settings. See <a href="#">"audit audit" on the next page</a> .
<b>log</b>	<b>l</b>	Manage the appliance logging settings. See <a href="#">"audit log" on page 20</a> .
<b>service</b>	<b>s</b>	Enable or disable the audit logging service. See <a href="#">"audit service" on page 24</a> .

## audit audit

Configure the **audit** user role.

### User access

**audit**

### Syntax

**audit audit**

**changepwd**

**init**

**secret**

Argument(s)	Shortcut	Description
<b>changepwd</b>	<b>c</b>	Change the <b>audit</b> user password. See " <a href="#">audit audit changepwd</a> " on the next page.
<b>init</b>	<b>i</b>	Initialize the <b>audit</b> user role. See " <a href="#">audit audit init</a> " on page 18.
<b>secret</b>	<b>s</b>	Generate the Audit secret key in the Admin token. You will be prompted to enter at least 3 parameters. If an Audit key is already present, it will be deleted. You must restart the HSM to put the new key in service. See " <a href="#">audit audit secret</a> " on page 19.



## audit audit changepwd

---

Change the **audit** user password.

### User access

**audit**

### Syntax

**audit audit changepwd**

### Example

```
psesh:>audit audit changepwd
```

```
Please Enter the old Auditor's PIN:
```

```
Please Enter the new Auditor's PIN:
```

```
Please re-enter the new Auditor's PIN:
```

```
Command Result : 0 (Success)
```

## audit audit init

---

Initialize the **audit** user role.

### User access

**audit**

### Syntax

**audit audit init**

### Example

```
psesh:>audit audit init
```

```
Please Enter the SO PIN:
```

```
Please Enter the new Auditor's PIN:
```

```
Please re-enter the new Auditor's PIN:
```

```
Command Result : 0 (Success)
```

## audit audit secret

---

Generate the Audit secret key in the Admin token. You will be prompted to enter at least 3 parameters. If an Audit key is already present, it will be deleted. You must restart the HSM to put the new key in service.

### User access

#### audit

### Syntax

#### audit audit secret

### Example

```
psesh:>audit audit secret
```

```
Please Enter the Auditor's PIN:  
Please enter number of params (minimum 3): 3  
Please enter parameter #0:12345678  
Please enter parameter #1:87654321  
Please enter parameter #2:01020304  
Audit Key created successfully
```

```
Command Result : 0 (Success)
```

## audit log

Configure the appliance logging settings.

### User access

#### audit

### Syntax

#### audit log

**clear**  
**rotation**  
**show**

Argument(s)	Shortcut	Description
<b>clear</b>	<b>c</b>	Destroy all audit logs currently on the HSM, without first backing them up to the appliance directory. See <a href="#">"audit log clear" on the next page</a> .  <b>CAUTION!</b> To back up the logs before deleting them, use <a href="#">"syslog tarlogs" on page 136</a> .
<b>rotation</b>	<b>r</b>	Set the appliance logging rotation schedule. See <a href="#">"audit log rotation" on page 22</a> .
<b>show</b>	<b>s</b>	Display the current appliance logging settings. See <a href="#">"audit log show" on page 23</a> .

## audit log clear

Destroy all audit logs currently on the HSM, without first backing them up to the appliance directory.

**CAUTION!** To back up the logs before deleting them, use ["syslog tarlogs" on page 136](#).

### User access

#### audit

### Syntax

#### audit log clear

### Example

```
psesh:>audit log clear
```

```
*** WARNING ***
```

```
All audit logs for this HSM will be destroyed (without backup)!!!
```

```
It is recommended to create a backup of audit logs first using "syslog tarlogs" command before destroying the logs!!!
```

```
Are you sure you wish to continue?
```

```
Type proceed to continue, or quit to quit now -> proceed
```

```
Command Result : 0 (Success)
```

## audit log rotation

Set the audit log rotation schedule. By default, the logs do not rotate.

### User access

#### audit

### Syntax

**audit log rotation [-hourly | -daily | -weekly]**

Argument(s)	Shortcut	Description
<b>-daily</b>	<b>-d</b>	Set a daily log rotation schedule.
<b>-hourly</b>	<b>-h</b>	Set an hourly log rotation schedule.
<b>-weekly</b>	<b>-w</b>	Set a weekly log rotation schedule.

### Example

```
psesh:>audit log rotation -daily
```

Setting Daily rotation.

Command Result : 0 (Success)

## audit log show

---

Display the current appliance logging settings.

### User access

#### **audit**

### Syntax

#### **audit log show**

### Example

```
psesh:>audit log show
```

```
Audit Logs Service is enabled.  
Using Hourly rotation
```

```
Command Result : 0 (Success)
```

## audit service

---

Enable or disable the audit logging service.

### User access

**audit**

### Syntax

**audit service**

**enable**

**disable**

Argument(s)	Shortcut	Description
<b>enable</b>	<b>e</b>	Enable the audit logging service. See <a href="#">"audit service enable" on page 26</a> .
<b>disable</b>	<b>d</b>	Disable the audit logging service. See <a href="#">"audit service disable" on the next page</a> .



## audit service disable

---

Disable the audit logging service.

### User access

#### audit

### Syntax

#### **audit service disable**

### Example

```
psesh:>audit service disable
```

```
Audit Log Service is disabled  
Stopping audittrace:  
Audit Log Service is stopped
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

---

## audit service enable

---

Enable the audit logging service.

### User access

#### audit

### Syntax

#### **audit service enable**

#### Example

```
psesh:>audit service enable
```

```
Audit Log is enabled
```

```
Starting audittrace:
```

```
Audit Log is started
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

## exit

---

Exit the PSESH shell. This ends the PSESH session.

### User access

**admin, pseoperator, audit**

### Syntax

**exit**

### Example

```
psesh:> exit
```

## files

Manage the files that have been transferred to the appliance using SCP. These files are automatically placed in the SCP directory, and cannot be moved.

### User access

admin, pseoperator

### Syntax

#### files

clear  
delete  
show

Argument(s)	Shortcut	Description
clear	c	Delete all of the files in the appliance's SCP directory. See <a href="#">"files clear" on the next page</a> .
delete	d	Delete the specified file from the appliance's SCP directory. See <a href="#">"files delete" on page 30</a> .
show	s	List all of the files that currently reside in the appliance's SCP directory. See <a href="#">"files show" on page 31</a> .

## files clear

---

Delete all of the files in the appliance's SCP directory.

### User access

**admin, pseoperator**

### Syntax

**files clear**

### Example

```
psesh:>files clear
This will delete all the files in the scp folder. Continue [y/n]?
> y
Proceeding....
All files deleted.
Command Result : 0 (Success)
```

## files delete

---

Delete the specified file from the appliance's SCP directory.

### User access

admin, pseoperator

### Syntax

**files delete -file** <filename>

Argument(s)	Shortcut	Description
-file <filename>	-f	Specifies the name of the file to delete.

### Example

```
psesh:>files delete PTKnetsrv-5.2.0-4.i386.rpm
This will delete file 'PTKnetsrv-5.2.0-4.i386.rpm' in the scp folder. Continue [y/n]?
> y
Proceeding....
File 'PTKnetsrv-5.2.0-4.i386.rpm' deleted.
Command Result : 0 (Success)
```

## files show

---

List all of the files that currently reside in the appliance's SCP directory.

### User access

**admin, pseoperator**

### Syntax

**files show**

### Example

```
psesh:> files show
SCP Folder Content
-----
total 861K
248K PTKnetsrv-5.2.0-4.i386.rpm
613K PTKpcihsMK6-5.2.0-4.i386.rpm
Command Result : 0 (Success)
```

# help

---

Display syntax help for the specified command. You can use the **?** symbol instead of the string **help** as an alternative way of displaying the help.

## User access

**admin, pseoperator, audit**

## Syntax

**help** <command>

## Example

```
psesh:>help help
```

Syntax:            help [<command>]

Type "help" or "?" (without the double quotation marks) to see help and syntax information for any PSE Shell command.

"help" or "?" with no arguments lists the top level commands with brief descriptions.

"help" or "?" followed by one or more arguments (command names, sub-commands, options) yields increasingly detailed information.

For example:

The command "? hsm" returns general information on the "hsm" commands.

The command "help hsm state" returns information on the "hsm state" subcommands.

The '-force' option, on any command that supports that option, causes the command to proceed silently, without prompting you for input - this is useful for scripting.

Command Result : 0 (Success)

```
psesh:> ? hsm
```

Syntax:            hsm

The following subcommands are available:

Name	(short)	Description
state	st	Shows HSM State
reset	r	Reset HSM
show	sh	Show Characteristics of the HSM

Command Result : 0 (Success)



## hsm

Display the current state of the HSM, information about the HSM, or reset the HSM if it becomes unresponsive.

### User access

admin, pseoperator

### Syntax

hsm

reset

show

state

Argument(s)	Shortcut	Description
reset	r	Reset the HSM if it has stopped responding, but your computer or the PSE appliance is still responsive. This command closes out any login status and open sessions. See <a href="#">"hsm reset" on the next page</a> .
show	sh	Display information about the appliance and the HSM, including appliance image and HSM firmware versions. See <a href="#">"hsm show" on page 35</a> .
state	st	Display the current state of the HSM adapter. See <a href="#">"hsm state" on page 36</a> .

## hsm reset

---

Reset the HSM if it has stopped responding, but your computer or the PSE appliance is still responsive. This command closes out any login status and open sessions.

### User access

admin, pseoperator

### Syntax

hsm reset

### Example

```
psesh:>hsm reset
```

```
Executing this command will disrupt all client connections. Proceed [y/n]?
```

```
> y
```

```
Proceeding to reset....
```

```
HSM reset successful.
```

```
Command Result : 0 (Success)
```

---

## hsm show

---

Display information about the appliance and the HSM, including appliance image and HSM firmware versions.

### User access

admin, pseoperator

### Syntax

hsm show

### Example

```
psesh:>hsm show
```

```
Appliance Details:
```

```
=====
```

```
Version          : Protect Server External II v5.9.0
ETNetServer      : Server active
```

```
HSM Details:
```

```
=====
```

```
Model            : PSI-E2:PL1500
Serial Number    : 518687
Firmware Version : 5.06.00
Hardware Status  : BATTERY OK  PCB v0  FPGA v0  EXT PINS 0
```

```
Command Result : 0 (Success)
```

## hsm state

---

Display the current state of the HSM adapter.

### User access

admin, pseoperator

### Syntax

hsm state

### Examples

```
psesh:>hsm state
```

```
HSM device 0:  HSM in NORMAL MODE. RESPONDING to requests. Usage Level=0%  
State = (0x8000, 0xffffffff)  
Host Interface  = PSIE2
```

```
Command Result : 0 (Success)
```

## network

View or configure the network settings for the ProtectServer External 2 appliance.

### User access

admin, pseoperator

### Syntax

#### network

**dns**  
**domain**  
**hostname**  
**interface**  
**iptables**  
**ping**  
**route**  
**show**

Argument(s)	Shortcut	Description
<b>dns</b>	<b>dn</b>	Add or delete DNS name servers and domains. See <a href="#">"network dns" on the next page</a> .
<b>domain</b>	<b>do</b>	Set the domain for the appliance. Enter this keyword followed by the domain name. See <a href="#">"network domain" on page 45</a> .
<b>hostname</b>	<b>h</b>	Set the host name for the appliance. See <a href="#">"network hostname" on page 46</a> .
<b>interface</b>	<b>in</b>	Configure the appliance network interfaces. See <a href="#">"network interface" on page 47</a> .
<b>iptables</b>	<b>ip</b>	Configure the iptables firewall for the appliance. You can use this command to configure the iptables ACCEPT and DROP rules. See <a href="#">"network iptables" on page 60</a> .
<b>ping</b>	<b>p</b>	Test connectivity from the appliance to the specified hostname or IP address. See <a href="#">"network ping" on page 72</a> .
<b>route</b>	<b>r</b>	Manually configure routes on the ProtectServer Network HSM appliance. See <a href="#">"network route" on page 73</a> .
<b>show</b>	<b>s</b>	Display the current network configuration. See <a href="#">"network show" on page 78</a> .

## network dns

---

Configure the Domain Name Server (DNS) settings on the ProtectServer Network HSM appliance. You can use this command to add or delete a DNS name server or search domain.

### User Access

admin

### Syntax

**network dns**

**add**

**delete**

Argument(s)	Shortcut	Description
<b>add</b>	<b>a</b>	Add a DNS name server or search domain to the system. See <a href="#">"network dns add" on the next page</a> .
<b>delete</b>	<b>d</b>	Delete a DNS name server or search domain from the appliance network configuration. See <a href="#">"network dns delete" on page 42</a> .

## network dns add

---

Add a DNS name server or search domain to the system.

### User Access

admin

### Syntax

**network dns add**

**nameserver**  
**searchdomain**

Argument(s)	Shortcut	Description
<b>nameserver</b>	<b>n</b>	Add a DNS name server to the list of servers used to provide DNS services to the appliance. See " <a href="#">network dns add nameserver</a> " on the next page.
<b>searchdomain</b>	<b>s</b>	Add a DNS search domain to the list of search domains that are automatically appended to URLs provided by the appliance. See " <a href="#">network dns add searchdomain</a> " on page 41.

---

## network dns add nameserver

---

Add a DNS name server to the list of servers used to provide DNS services to the appliance.

### User Access

admin

### Syntax

**network dns add nameserver** <IP\_address>

Argument(s)	Shortcut	Description
<IP_address>		Specifies the IP address of the DNS server you want to add to the DNS table on the appliance.

### Example

```
psesh:> net dns add nameserver 192.16.0.2
Success: Nameserver 192.16.0.2 added
```



## network dns add searchdomain

Add a DNS search domain to the list of search domains that are automatically appended to URLs provided by the appliance.

### User Access

admin

### Syntax

**network dns add searchdomain** <netdomain>

Argument(s)	Shortcut	Description
<netdomain>		Specifies the DNS search domain to be added to the list of search domains that are automatically appended to URLs provided by the appliance.

### Example

```
psesh:> net dns add searchdomain 192.16.0.0  
Success: Searchdomain entry 192.16.0.0 added
```

## network dns delete

Delete a DNS name server or search domain from the appliance network configuration.

### User Access

admin

### Syntax

**network dns delete**

**nameserver**  
**searchdomain**

Argument(s)	Shortcut	Description
<b>nameserver</b>	<b>n</b>	Delete a DNS name server from the list of servers used to provide DNS services to the appliance. See " <a href="#">network dns delete nameserver</a> " on the next page.
<b>searchdomain</b>	<b>s</b>	Delete a DNS search domain from the list of search domains that are automatically appended to URLs provided by the appliance. See " <a href="#">network dns delete searchdomain</a> " on page 44.

---

## network dns delete nameserver

---

Delete a DNS name server from the list of servers used to provide DNS services to the appliance.

### User Access

admin

### Syntax

**network dns delete nameserver** <IP\_address>

Argument(s)	Shortcut	Description
<IP_address>		Specifies the IP address of the DNS server you want to delete from the DNS table on the appliance.

### Example

```
psesh:> net dns delete nameserver 192.16.0.2
Success: Nameserver 192.16.0.2 deleted
```

## network dns delete searchdomain

Delete a DNS search domain from the list of search domains that are automatically appended to URLs provided by the appliance.

### User Access

admin

### Syntax

**network dns delete searchdomain** <netdomain>

Argument(s)	Shortcut	Description
<netdomain>		Specifies the DNS search domain to be deleted from the list of search domains that are automatically appended to URLs provided by the appliance.

### Example

```
psesh:> net dns delete searchdomain 192.16.0.0
Success: Searchdomain entry 192.16.0.0 deleted
```

## network domain

---

Set the domain for the appliance. Enter this keyword followed by the domain name.

### User access

admin, pseoperator

### Syntax

**network domain** <domain>

Argument(s)	Shortcut	Description
<domain>		Specifies the domain for the appliance.

### Example

```
psesh:>network domain hmsdomain
Success: DomainName hmsdomain set.
Command Result : 0 (Success)
```

## network hostname

---

Set the host name for the appliance.

### User access

admin, pseoperator

### Syntax

**network hostname** <hostname>

Argument(s)	Shortcut	Description
<hostname>		Specifies the host name for the appliance.

### Example

```
psesh:>network hostname hsmhost
Success: Hostname hsmhost set.
Command Result : 0 (Success)
```

## network interface

Configure the appliance network interfaces. You can use static IP addressing or DHCP.

### User Access

admin

### Syntax

#### network interface

**bonding**  
**delete**  
**dhcp**  
**ipv6**  
**static**

Argument(s)	Shortcut	Description
<b>bonding</b>	<b>b</b>	Configure network interface bonding. See " <a href="#">network interface bonding</a> " on the next page.
<b>delete</b>	<b>del</b>	Delete the network configuration for a network interface (eth0 or eth1). See " <a href="#">network interface delete</a> " on page 55.
<b>dhcp</b>	<b>dh</b>	Set a network interface with a DHCP IP configuration. See " <a href="#">network interface dhcp</a> " on page 56.
<b>ipv6</b>	<b>ipv</b>	Configure an IPv6 address. See " <a href="#">network interface ipv6</a> " on page 59.
<b>static</b>	<b>s</b>	Sets a network interface with a static IP configuration. See " <a href="#">network interface static</a> " on page 57.

**NOTE** Static IPv4 addressing is the default. The following syntax can be used to set a network interface using default addressing:

**network interface -device <netdevice> -ip <IP> -netmask <IP> [-gateway <IP>] [-force]**

See "[network interface static](#)" on page 57 for descriptions of the arguments used in the preceding syntax.

## network interface bonding

Bond two network interfaces into a single virtual device. Creating a bonded interface provides redundant failover in the event of a port failure, and improves bandwidth. When bonded, two interfaces appear as a single physical device with the same MAC address.

### User Access

admin

### Syntax

#### network interface bonding

config  
disable  
enable  
show

Argument(s)	Shortcut	Description
config	c	Configure the network bonding interface. See <a href="#">"network interface bonding config" on the next page</a> .
disable	d	Disable the bonding interface. See <a href="#">"network interface bonding disable" on page 52</a> .
enable	e	Enable the bonding interface using the current configuration. See <a href="#">"network interface bonding enable" on page 53</a> .
show	s	Show bond configuration information. See <a href="#">"network interface bonding show" on page 54</a> .



## network interface bonding config

Configure the network bonding interface. There are multiple modes available.

### User Access

admin

### Syntax

**network interface bonding config -ip <IP> -netmask <IP> -devices <devices> [-gateway <IP>] [-mode <mode>]**

Argument(s)	Shortcut	Description
<b>-devices</b> <devices>	-d	Specifies the network devices to assign to the bonded device. Use a comma-separated list of valid devices. <b>Valid Values:</b> > eth0 > eth1
<b>-gateway</b> <IP>	-g	Specifies the gateway to assign to the bonded device.
<b>-ip</b> <IP>	-i	Specifies the IP address to assign to the bonded device. <b>NOTE</b> Configure network interface bonding with static IPv4 addresses only.

Argument(s)	Shortcut	Description
<b>-mode</b> <mode>	<b>-m</b>	<p>Specifies the bonding mode (default: <b>0</b>).</p> <p><b>Valid Values:</b></p> <ul style="list-style-type: none"> <li>&gt; <b>0:</b> Balance Round Robin. Packets are transmitted alternately on each device in the bond, providing load balancing and fault tolerance.</li> <li>&gt; <b>1:</b> Active-Backup. One bonded device is active and the other serves as a backup. The backup only becomes active if the active device loses connectivity.</li> <li>&gt; <b>2:</b> Balance XOR. Transmits based on an XOR formula, where the source MAC address is XOR'd with the destination MAC address. The same bonded device is selected for each destination MAC address, providing load balancing and fault tolerance.</li> <li>&gt; <b>3:</b> Broadcast. All packets are transmitted on both bonded interfaces, providing fault tolerance.</li> <li>&gt; <b>4:</b> 802.3ad (Dynamic Link Aggregation). Creates aggregated groups that share the same speed and duplex settings. This mode requires a switch that supports IEEE 802.3ad dynamic links. The device used for an outgoing packet is selected by the transmit hash policy (by default, a simple XOR). This policy can be changed via the <code>xmit_hash_policy</code> option. <b>NOTE:</b> Check the 802.3ad standard to ensure that your transmit policy is 802.3ad-compliant. In particular, check section 43.2.4 for packet mis-ordering requirements. Non-compliance tolerance may vary between different peer implementations.</li> <li>&gt; <b>5:</b> Balance TLB (Transmit Load Balancing). Outgoing traffic is distributed according to the current load and queue on each bonded device. Incoming traffic is received by the current device.</li> <li>&gt; <b>6:</b> Balance ALB (Adaptive Load Balancing). Both outgoing and incoming traffic is load-balanced like outgoing traffic in mode 5. Incoming load balancing is governed by ARP negotiation. The bonding driver intercepts the ARP replies sent by the appliance and overwrites the source hardware address with the unique hardware address of one of the bonded devices. Different clients will therefore use different hardware addresses for the appliance.</li> </ul>
<b>-netmask</b> <IP>	<b>-n</b>	<p>Specifies the network mask, in dotted-decimal format (for example, 255.255.255.0), to assign to the bonded device.</p>

### Example

```
psesh:>network interface bonding config -ip 192.20.11.10 -netmask 255.255.255.0 -mode 1
```

NIC Bonding configured

Command Result : 0 (Success)

## network interface bonding disable

---

Disable network interface bonding.

### User Access

**admin**

### Syntax

**network interface bonding disable**

### Example

```
psesh:>network interface bonding disable
```

```
NIC Bonding disabled
```

```
Command Result : 0 (Success)
```

## network interface bonding enable

---

Enable the current bonding configuration.

### User Access

**admin**

### Syntax

**network interface bonding enable**

### Example

```
psesh:>network interface bonding enable
```

```
NIC Bonding enabled  
MUST RESTART SYSTEM TO SET THE CORRECT BONDING PARAMETERS!!!
```

```
Command Result : 0 (Success)
```

---

## network interface bonding show

---

Display the current bond configuration.

### User Access

**admin**

### Syntax

**network interface bonding show**

### Example

```
psesh:>network interface bonding show
```

Bonding is configured, but not enabled.

```
===== Bonding Interface =====  
BOOTPROTO=static  
IPADDR=192.20.11.99  
NETMASK=255.255.255.0  
BOND MODE= (Balance Round Robin)  
=====
```

```
Command Result : 0 (Success)
```

## network interface delete

Delete the network configuration for a network interface (eth0 or eth1).

### User Access

admin

### Syntax

**network interface delete -device <netdevice>**

Argument(s)	Shortcut	Description
<b>-device &lt;netdevice&gt;</b>	<b>-d</b>	Specifies the interface whose configuration you want to delete. <b>Valid Values:</b> <ul style="list-style-type: none"><li>&gt; eth0</li><li>&gt; eth1</li><li>&gt; bond0</li></ul>

### Example

```
psesh:> network interface delete -device eth1
```

```
Interface eth1 removed successfully.
```

```
Command Result : 0 (Success)
```

## network interface dhcp

Configure the network interface to request a dynamic IP address.

**NOTE** DHCP is not recommended.

### User Access

admin

### Syntax

**network interface dhcp -device** <netdevice> [-force]

Argument(s)	Shortcut	Description
<b>-device</b> <netdevice>	<b>-d</b>	Specifies the interface you want to configure to use DHCP. <b>Valid Values:</b> > eth0 > eth1 > bond0
<b>-force</b>	<b>-f</b>	Force the action without prompting for confirmation.

### Example

```
psesh:>network interface dhcp -device eth0
```

NOTICE: The network service must be restarted for new network settings to take effect. If you are sure that you wish to restart the network, then type 'proceed', otherwise type 'quit'

```
> proceed
Proceeding...
e1000e: eth0 NIC Link is Down
Restarting network service...
Shutting down loopback interface:                [ OK ]
Bringing up loopback interface:                  [ OK ]
Bringing up interface eth0:
Determining IP information for eth0...ADDRCONF(NETDEV_UP): eth0: link is not ready
e1000e: eth0 NIC Link is Up 1000 Mbps Full Duplex, Flow Control: None
ADDRCONF(NETDEV_CHANGE): eth0: link becomes ready
done.
[ OK ]
```

Command Result : 0 (Success)



## network interface static

Configure a static IP address on the specified network interface.

### User Access

admin

### Syntax

**network interface static -device** <netdevice> **-ip** <IP\_address> **-netmask** <IP\_address> [**-gateway** <IP\_address>] [**-force**]

Argument(s)	Shortcut	Description
<b>-device</b> <netdevice>	<b>-d</b>	Specifies the interface you want to configure. <b>Valid Values:</b> > <b>eth0</b> > <b>eth1</b> > <b>bond0</b>
<b>-ip</b> <IP_address>	<b>-i</b>	Specifies the IP address to assign to the specified device.
<b>-netmask</b> <IP_address>	<b>-n</b>	Specifies the network mask, in dotted-decimal format (for example, 255.255.255.0), to assign to the specified device.
<b>-gateway</b> <IP_address>	<b>-g</b>	Specifies the gateway to assign to the specified device.
<b>-force</b>	<b>-f</b>	Force the action without prompting.

### Example

```
psesh:>network interface static -device eth0 -ip 172.20.11.40 -netmask 255.255.255.0
```

NOTICE: The network service must be restarted for new network settings to take effect. If you are sure that you wish to restart the network, then type 'proceed', otherwise type 'quit'

```
> proceed
Proceeding...
e1000e: eth0 NIC Link is Down
Restarting network service...
Shutting down loopback interface:           [ OK ]
Bringing up loopback interface:             [ OK ]
Bringing up interface eth0: ADDRCONF(NETDEV_UP): eth0: link is not ready
Determining if ip address 172.20.11.40 is already in use for device eth0...
                                                [ OK ]
e1000e: eth0 NIC Link is Up 1000 Mbps Full Duplex, Flow Control: None
```

```
ADDRCONF(NETDEV_CHANGE): eth0: link becomes ready
```

```
Command Result : 0 (Success)
```

## network interface ipv6

Configure a static IPv6 address on the specified network interface. IPv6 addresses must be static; DHCP is not supported.

### User Access

admin

### Syntax

**network interface ipv6 -device <netdevice> -ip <IPv6\_address> [-gateway <IP\_address>] [-force]**

Argument(s)	Shortcut	Description
<b>-device</b> <netdevice>	<b>-d</b>	Specifies the interface you want to configure. <b>Valid Values:</b> > <b>eth0</b> > <b>eth1</b> > <b>bond0</b>
<b>-ip</b> <IP_address>	<b>-i</b>	Specifies the IPv6 address to assign to the specified device.
<b>-gateway</b> <IP_address>	<b>-g</b>	Specifies the IPv6 gateway to assign to the specified device.
<b>-force</b>	<b>-f</b>	Force the action without prompting.

## network iptables

Configure the iptables firewall for the appliance. You can use this command to configure the iptables ACCEPT and DROP rules.

By default, the ProtectServer Network HSM allows access to all networks and hosts. The default policy for the INPUT and OUTPUT chain is set to ACCEPT. The default policy for the FORWARD chain is set to DROP, since the ProtectServer Network HSM is not used to forward packets, as in a router or proxy.

### User Access

admin, pseoperator

### Syntax

#### network iptables

addrule  
clear  
delrule  
save  
show

Argument(s)	Shortcut	Description
addrule	a	Add an ACCEPT or DROP rule to the iptables firewall for the appliance. See <a href="#">"network iptables addrule" on the next page</a> .
clear	c	Clear the iptables for the device. This returns the iptables to a factory default state. See <a href="#">"network iptables clear" on page 68</a> .
delrule	d	Deletes the specified "INPUT" chain rule in iptables. Run <b>network iptables show</b> to see the rule numbers. See <a href="#">"network iptables delrule" on page 69</a>
save	sa	Saves the iptables changes. You must execute this command or any changes will be discarded on the next appliance restart. See <a href="#">"network iptables save" on page 70</a> .
show	sh	Display the current iptables configuration. See <a href="#">"network iptables show" on page 71</a> .

## network iptables addrule

Add an ACCEPT or DROP rule to the iptables firewall for the appliance.

**\*\*WARNING\*\*** These rules govern network access to the appliance. Adding a malformed rule may cause a lockout.

**NOTE** You must use the **network iptables save** command to save your changes. Failure to do so will result in your changes being discarded on the next appliance restart.

### User Access

admin

### Syntax

**network iptables addrule**

**accept**  
**drop**

Argument(s)	Shortcut	Description
<b>accept</b>	<b>a</b>	Add a host or network ACCEPT rule to the iptable for the appliance. See <a href="#">"network iptables addrule accept" on the next page</a> .
<b>drop</b>	<b>d</b>	Add a host or network DROP rule to the iptable for the appliance. See <a href="#">"network iptables addrule drop" on page 65</a> .

## network iptables addrule accept

Add a host or network ACCEPT rule to the iptable for the appliance.

### User Access

admin

### Syntax

**network iptables addrule accept**

**host**

**network**

Argument(s)	Shortcut	Description
<b>host</b>	<b>h</b>	Adds a host ACCEPT rule to the iptables firewall for the appliance. See <a href="#">"network iptables addrule accept host" on the next page</a> .
<b>network</b>	<b>n</b>	Adds a network ACCEPT rule to the iptables firewall for the appliance. See <a href="#">"network iptables addrule accept network" on page 64</a> .

## network iptables addrule accept host

Adds a host ACCEPT rule to the iptables firewall for the appliance.

### User Access

admin

### Syntax

**network iptables addrule accept host -ip <IP\_address>**

Argument(s)	Shortcut	Description
-ip <IP_address>	-i	Specifies the IP address of the host you are adding the rule for.

### Example

```
psesh:>network iptables addrule accept host -ip 172.20.11.105
ACCEPT rule added for host 172.20.11.105
Command Result : 0 (Success)
```

## network iptables addrule accept network

Adds a network ACCEPT rule to the iptables firewall for the appliance.

### User Access

admin

### Syntax

**network iptables addrule accept network -net**<IP\_address> **-mask** <netmask>

Argument(s)	Shortcut	Description
<b>-net</b> <IP_address>	<b>-n</b>	Specifies the IP address for the network you are adding the rule for.
<b>-mask</b> <netmask>	<b>-m</b>	Specifies the network mask for the network you are adding the rule for.

### Example

```
psesh:>network iptables addrule accept network -net 10.124.93.157 -mask 255.255.254.0
```

```
ACCEPT rule added for 10.124.93.157/255.255.254.0 network
```

```
Command Result : 0 (Success)
```



## network iptables addrule drop

Adds a host or network DROP rule to the iptable for the appliance.

### User Access

admin

### Syntax

**network iptables addrule drop**

**host**

**network**

Argument(s)	Shortcut	Description
<b>host</b>	<b>h</b>	Adds a host DROP rule to the iptables firewall for the appliance. See <a href="#">"network iptables addrule drop host" on the next page</a> .
<b>network</b>	<b>n</b>	Adds a network DROP rule to the iptables firewall for the appliance. See <a href="#">"network iptables addrule drop network" on page 67</a> .

## network iptables addrule drop host

Adds a host DROP rule to the iptables firewall for the appliance.

### User Access

admin

### Syntax

**network iptables addrule drop host -ip <IP\_address>**

Argument(s)	Shortcut	Description
-ip <IP_address>	-i	Specifies the IP address of the host you are adding the rule for.

### Example

```
psesh:>network iptables addrule drop host -ip 10.124.93.19
```

```
DROP rule added for host 10.124.93.19
```

```
Command Result : 0 (Success)
```

## network iptables addrule drop network

Adds a network DROP rule to the iptables firewall for the appliance.

### User Access

admin

### Syntax

**network iptables addrule drop network -net<IP\_address> -mask <netmask>**

Argument(s)	Shortcut	Description
<b>-net</b> <IP_address>	<b>-n</b>	Specifies the IP address for the network you are adding the rule for.
<b>-mask</b> <netmask>	<b>-m</b>	Specifies the network mask for the network you are adding the rule for.

### Example

```
psesh:>network iptables addrule drop network -net 172.20.11.212 -mask 255.0.255.0
DROP rule added for 172.20.11.212/255.0.255.0 network
Command Result : 0 (Success)
```

---

## network iptables clear

---

Clear the iptables for the device. This returns the iptables to a factory default state.

### User Access

**admin**

### Syntax

**network iptables clear**

### Example

```
psesh:>network iptables clear
```

```
WARNING: This will delete all configured rules and reset iptables to factory default. Proceed  
[y/n]?
```

```
> y
```

```
Proceeding....
```

```
clearing iptables...
```

```
Restarting network service...please wait
```

```
Command Result : 0 (Success)
```

## network iptables delrule

Deletes the specified "INPUT" chain rule in iptables. Run `network iptables show` to see the rule order.

### User Access

admin

### Syntax

**network iptables delrule -rulenum <number>**

Argument(s)	Shortcut	Description
<b>-rulenum</b> <number>	<b>-r</b>	The number of the rule to be deleted.

### Example

```
psesh:>network iptables delrule -rulenum 2
```

```
iptables: Rule 2 deleted.
```

```
Command Result : 0 (Success)
```

## network iptables save

---

Saves the iptables changes. You must execute this command or any changes will be discarded on the next appliance restart.

### User Access

**admin**

### Syntax

**network iptables save**

### Example

```
psesh:>network iptables save
```

```
WARNING: This will save all the iptables changes and restart the network services. Proceed  
[y/n]?
```

```
>
```

```
Exiting....
```

```
Command Result : 0 (Success)
```

---

## network iptables show

---

Display the current iptables configuration.

### User Access

**admin, pseoperator**

### Syntax

**network iptables show**

### Example

```
psesh:>network iptables show
```

Current iptables rules:

```
Chain INPUT (policy ACCEPT)
target     prot opt source                               destination
ACCEPT     all  --  172.20.11.105                          anywhere
DROP       all  --  172.20.11.105                          anywhere
DROP       all  --  172-0-11-0.lightspeed.wlfrct.sbcglobal.net/255.0.255.0  anywhere
```

```
Command Result : 0 (Success)
```

## network ping

Test connectivity from the appliance to the specified hostname or IP address.

### User access

admin, pseoperator

### Syntax

**network ping** <hostname/IP>

Argument(s)	Shortcut	Description
<hostname/IP>		Specifies the host name or IP address of the host you want to ping.

### Example

```
psesh:>network ping 10.124.0.65
```

```
PING 10.124.0.65 (10.124.0.65) 56(84) bytes of data.  
64 bytes from 10.124.0.65: icmp_seq=1 ttl=126 time=18.5 ms
```

```
--- 10.124.0.65 ping statistics ---  
1 packets transmitted, 1 received, 0% packet loss, time 18ms  
rtt min/avg/max/mdev = 18.534/18.534/18.534/0.000 ms
```

```
Command Result : 0 (Success)
```



## network route

Manage and view network route configurations.

### User Access

admin, pseoperator

### Syntax

#### network route

add  
clear  
delete  
show

Argument(s)	Shortcut	Description
add	a	Adds a manually configured network route. See <a href="#">"network route add" on the next page</a> . <b>Note:</b> This command should only be used on the advice of a network administrator.
clear	c	Deletes all manually configured network routes. See <a href="#">"network route clear" on page 75</a> . <b>Note:</b> This command should only be used on the advice of a network administrator.
delete	d	Deletes one manually configured network route. See <a href="#">"network route delete" on page 76</a> . <b>Note:</b> This command should only be used on the advice of a network administrator.
show	s	Shows the current network route configuration. See <a href="#">"network route show" on page 77</a> .

## network route add

Manually add a network route to the appliance's routing tables.

**CAUTION!** Use this command only under the advice and supervision of your network administrator.

### User Access

admin

### Syntax

**network route add** <route\_type> <IP\_address> [-**device** <interface>] [-**metric** <metric>] [-**netmask** <netmask>] -**gateway** <IP\_address>] [-**force**]

Argument(s)	Shortcut	Description
<route_type>		Specifies the type of route you want to add. <b>Valid values:</b> host, network
<IP_address>		Specifies the IP address of the route you want to add.
- <b>device</b> <interface>	- <b>d</b>	Specifies the interface you want to configure. <b>Valid values:</b> eth0, eth1
- <b>metric</b> <metric>	- <b>m</b>	Specifies the routing metric for the route. <b>Range:</b> 0-65535
- <b>netmask</b> <netmask>	- <b>n</b>	Specifies the network mask for the route, in dotted-decimal format (for example, 255.255.255.0).
- <b>gateway</b> <IP_address>	- <b>g</b>	Specifies the IP address of the gateway for the route.
- <b>force</b>	- <b>f</b>	Force the action without prompting.

## network route clear

Delete all manually-configured network routes from the appliance's routing tables.

**CAUTION!** Use this command only under the advice and supervision of your network administrator.

### User Access

admin

### Syntax

**network route clear**

### Example

```
psesh:>network route clear
```

```
WARNING !! This command deletes all manually configured routes and restarts the network service.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
>proceed
```

```
Proceeding...
```

```
Restarting network service...
```

```
ip_tables: (C) 200-2006 Netfilter Core Team
```

```
Shutting down interface eth0: e1000e: eth0 NIC Link is Down
```

```
[ OK ]
```

```
Shutting down loopback interface:
```

```
[ OK ]
```

```
Bringing up loopback interface:
```

```
[ OK ]
```

```
Bringing up interface eth0
```

```
Determining IP information for eth0...ADDRCONF(NETDEV_UP): eth0: link is not ready
```

```
e1000e: eth0 NIC Link is Up 1000 Mbps Full Duplex, Flow Control: None
```

```
ADDRCONF(NETDEV_CHANGE): eth0: link becomes ready
```

```
done.
```

```
[ OK ]
```

```
ip_tables: (C) 200-2006 Netfilter Core Team
```

```
Routing table successfully updated.
```

```
Command Result : 0 (Success)
```

## network route delete

Delete a manually-configured network route from the appliance's routing tables.

**CAUTION!** Use this command only under the advice and supervision of your network administrator.

### User Access

admin

### Syntax

**network route delete** <route\_type> <IP\_address> [-device <interface>] [-metric <metric>] [-netmask <netmask>] [-gateway <IP\_address>] [-force]

Argument(s)	Shortcut	Table Section Outside Table: Description
<route_type>		Specifies the type of route you want to delete. <b>Valid values:</b> host, network
<IP_address>		Specifies the IP address of the route you want to delete.
-device <interface>	-d	Specifies the interface you want to configure. <b>Valid values:</b> eth0, eth1
-metric <metric>	-m	Specifies the routing metric for the route. <b>Range:</b> 0-65535
-netmask <netmask>	-n	Specifies the network mask for the route, in dotted-decimal format (for example, 255.255.255.0).
-gateway <IP_address>	-g	Specifies the IP address of the gateway for the route.
-force	-f	Force the action without prompting.

## network route show

---

Shows the current network route configuration.

### User Access

**admin, pseoperator**

### Syntax

**network route show**

### Example

```
psesh:>network route show
```

```
Kernel IP routing table
Destination      Gateway          Genmask         Flags Metric Ref    Use Iface
172.20.11.0      0.0.0.0         255.255.255.0  U         0      0      0 eth0
169.254.0.0     0.0.0.0         255.255.0.0   U        1002   0      0 eth0
0.0.0.0         172.20.11.10   0.0.0.0       UG         0      0      0 eth0
```

```
Command Result : 0 (Success)
```

## network show

Display the current network configuration.

### User access

**admin, pseoperator**

### Syntax

**network show**

### Example

```
psesh:>network show
```

```

Hostname:          "hsmhost"
Domain:            "hsmdomain"

IP Address (eth0): 172.20.11.40
HW Address (eth0): 00:01:4E:02:D1:59
Mask (eth0):       255.255.255.0
Gateway (eth0):    <not set>

Name Servers:      172.20.10.20      172.16.2.14
Search Domain(s): <not set>
```

Kernel IP routing table

Destination	Gateway	Genmask	Flags	Metric	Ref	Use	Iface
172.20.11.0	0.0.0.0	255.255.255.0	U	0	0	0	eth0
169.254.0.0	0.0.0.0	255.255.0.0	U	1002	0	0	eth0
0.0.0.0	172.20.11.10	0.0.0.0	UG	0	0	0	eth0

Link status

```
eth0: Configured
      Link detected: yes
```

```
eth1: Not configured
```

```
Command Result : 0 (Success)
```

## package

---

Manage the software packages installed on the appliance.

### User access

admin

### Syntax

**package**

**list**

**install**

**listfile**

Argument(s)	Shortcut	Description
<b>list</b>	<b>l</b>	List the packages currently installed on the appliance. See <a href="#">"package list" on the next page</a> .
<b>install&gt;</b>	<b>i</b>	Install the update contained in the specified secure package file (*.spkg). See <a href="#">"package install" on page 83</a> .
<b>listfile</b>	<b>listf</b>	Display a list of all the secure package files you have transferred to the appliance. See <a href="#">"package listfile" on page 84</a> .

## package list

---

List the packages currently installed on the appliance.

### User access

admin

### Syntax

#### package list

all

ptk

Argument(s)	Shortcut	Description
all	a	Lists all packages installed on the appliance. See " <a href="#">package list all</a> " on the next page.
ptk	p	Lists only the ProtectToolkit packages installed on the appliance. See " <a href="#">package list ptk</a> " on page 82.



---

## package list all

---

List all packages installed on the appliance.

### User access

**admin**

### Syntax

**package list all**

### Example

```
psesh:>package list all
```

```
filesystem-2.4.30-3.el6.i686  
ncurses-base-5.7-3.20090208.el6.i686  
kbd-misc-1.15-11.el6.noarch
```

```
...
```

```
pciutils-3.1.10-4.el6.i686  
audit-2.3.7-5.el6.i686  
e2fsprogs-1.41.12-21.el6.i686  
acl-2.2.49-6.el6.i686  
PTKpcihsM6-5.2.0-5.i386  
PTKnetsrv-5.2.0-5.i386
```

```
Command Result : 0 (Success)
```

## package list ptk

---

Lists only the ProtectToolkit packages installed on the appliance.

### User access

**admin**

### Syntax

**package list ptk**

### Example

```
psesh:>package list ptk
```

```
PTKpcihsMK6-5.2.0-5.i386
```

```
PTKnetsrv-5.2.0-5.i386
```

```
Command Result : 0 (Success)
```

## package install

Install the update contained in the specified secure package file (\*.spkg). You must include the authorization code string found in the included **authcode.txt** file. Specify the string itself; you cannot specify the **.txt** file with the **-authcode** parameter. Use **scp/pscp** to securely transfer the secure package file to the appliance.

### User access

admin

### Syntax

**package install -spkgfile** <spkg\_file> **-authcode** <auth\_code>

Argument(s)	Shortcut	Description
<b>-spkgfile</b> <spkg_file>	<b>-s</b>	Specifies the secure package file (*.spkg).
<b>-authcode</b> <auth_code>	<b>-a</b>	Specifies the authorization code string found in the included <b>authcode.txt</b> file.

### Example

```
psesh:>package install -s test.spkg -a 5C6DF95B7F6837FD62E000
```

```
Please Enter the Admin Token PIN:
```

```
Decryption Successful
```

```
Signature Verification Successful
```

```
Preparing packages for installation...
```

```
dummy-package2-1.0-1
```

```
Preparing packages for installation...
```

```
dummy-package1-1.0-1
```

```
RPM installation Successful
```

```
SPKG package installation successful.
```

```
Command Result : 0 (Success)
```

**NOTE** When installing a secure package on ProtectServer Network HSM Plus, the following error message may be displayed:

```
IRQ 16/viper0: IRQF_DISABLED is not guaranteed on shared IRQs
```

This does not affect any part of the installation and can be safely ignored.

## package listfile

---

Display a list of all the secure package files you have transferred to the appliance.

### User access

**admin**

### Syntax

**package listfile**

### Examples

```
psesh:>package listfile
```

```
Available Packages:
```

```
test.spkg  
test2.spkg  
test3.spkg  
test4.spkg  
test_rsa2.spkg
```

```
Command Result : 0 (Success)
```

## service

Manage the following services on the appliance:

- > **network** - Network service (needed for **etnetserver**, **ssh**, and **scp**)
- > **etnetserver** - HSM service required for client connections
- > **audittrace** - HSM service required for audit logging (this service can only be affected by the **audit** user)
- > **iptables** - Firewall service
- > **snmp** - SNMP agent service
- > **ssh** - Secure shell service (needed for **ssh** and **scp**)
- > **syslog** - Syslog service

### User access

**admin, pseoperator**

### Syntax

#### service

**list**  
**restart**  
**start**  
**status**  
**stop**

Argument(s)	Shortcut	Description
<b>list</b>	<b>l</b>	List the services you can manage on the appliance. See " <a href="#">service list</a> " on the next page.
<b>restart</b>	<b>r</b>	Restart the specified service. See " <a href="#">service restart</a> " on page 87.
<b>start</b>	<b>star</b>	Start the specified service. See " <a href="#">service start</a> " on page 88.
<b>status</b>	<b>stat</b>	Display the status (stopped, running) of the specified service. See " <a href="#">service status</a> " on page 89.
<b>stop</b>	<b>sto</b>	Stop the specified service. See " <a href="#">service stop</a> " on page 90.

---

## service list

---

List the services you can manage on the appliance.

### User access

**admin, pseoperator**

### Syntax

**service list**

### Example

```
psesh:>service list
```

The following are valid PSe service names:

```
network      - Network service (Needed for etnetserver, ssh and scp)
etnetserver  - HSM service required for client connections
audittrace   - HSM service required for audit logs
iptables     - Firewall Service
snmp         - SNMP agent service
ssh          - Secure shell service (Needed for ssh and scp)
syslog       - Syslog service
```

```
Command Result : 0 (Success)
```

## service restart

Restart the specified service. Services require restarting if their configurations have changed. For example, after changing any network settings using the network commands, you should restart the network service to ensure the new settings take effect. Restarting a service isn't always the same as stopping and then starting a service. If you restart the network service while connected to the appliance via the network (ssh), you will not lose your connection (assuming no changes were made that would cause a connection loss). However, if you were to stop the network service, you would immediately lose your connection, and you would need to log in via the local console to start the service again.

### User access

admin, pseoperator

### Syntax

**service restart** <service>

Argument(s)	Shortcut	Description
<service>		Specifies the service to restart. <b>Valid values:</b> network, etnetserver, iptables, snmp, ssh, syslog

### Example

```
psesh:>service restart syslog
```

```
Shutting down system logger:           [ OK ]
Starting system logger:                 [ OK ]
```

```
Command Result : 0 (Success)
```

```
psesh:>service restart network
```

```
Shutting down interface eth0:          [ OK ]
Shutting down interface eth1:          [ OK ]
Shutting down loopback interface:      [ OK ]
Bringing up loopback interface:        [ OK ]
Bringing up interface eth0:            [ OK ]
Bringing up interface eth1:            [ OK ]
Determining IP information for eth0... done. [ OK ]
Determining IP information for eth1... done. [ OK ]
```

```
Command Result : 0 (Success)
```

## service start

---

Start the specified service.

### User access

admin, pseoperator

### Syntax

**service start** <service>

Argument(s)	Shortcut	Description
<service>		Specifies the service to start. <b>Valid values:</b> network, etnetserver, iptables, snmp, syslog.

### Example

```
psesh:>service start syslog
```

```
Starting system logger:           [ OK ]
Starting kernel logger:          [ OK ]
```

```
Command Result : 0 (Success)
```



## service status

---

Display the status (stopped, running) of the specified service.

### User access

admin, pseoperator

### Syntax

**service status** <service>

Argument(s)	Shortcut	Description
<service>		Specifies the service whose status will be displayed. <b>Valid values:</b> network, etnetserver, iptables, snmp, ssh, syslog.

### Example

```
psesh:>service status ssh
```

```
ssh is running
```

```
Command Result : 0 (Success)
```

## service stop

---

Stop the specified service.

### User access

admin, pseoperator

### Syntax

#### service stop

Argument(s)	Shortcut	Description
<service>		Specifies the service to stop. <b>Valid values:</b> network, etnetserver, iptables, snmp, syslog.

### Example

```
psesh:>service stop syslog
```

```
Shutting down system logger: [ OK ]
```

```
Command Result : 0 (Success)
```

# status

Display the current status of the appliance.

## User access

admin, pseoperator

## Syntax

### status

cpu  
date  
disk  
interface  
mac  
mem  
netstat  
ps  
time  
zone

Argument(s)	Shortcut	Description
cpu	c	Display the current CPU load. See <a href="#">"status cpu" on page 93</a> .
date	da	Display the current date and time. See <a href="#">"status date" on page 94</a> .
disk	di	Display hard disk utilization. See <a href="#">"status disk" on page 95</a> .
interface	i	Display configuration and status information for the eth0 and eth1 interfaces. See <a href="#">"status interface" on page 96</a> .
mac	ma	Display the MAC address of the eth0 and eth1 interfaces, if they have been configured. See <a href="#">"status mac" on page 97</a> .
mem	me	Display the current memory usage. See <a href="#">"status mem" on page 98</a> .
netstat	n	Display the current network connections. See <a href="#">"status netstat" on page 99</a> .
ps	p	Display the status of all active processes. See <a href="#">"status ps" on page 100</a> .
time	t	Display the time currently configured on the appliance, using the 24 hour clock. See <a href="#">"status time" on page 102</a> .

---

Argument(s)	Shortcut	Description
zone	z	Display the currently configured time zone. See " <a href="#">status zone</a> " on <a href="#">page 103</a> .

---

---

## status cpu

---

The CPU load data is presented as a series of five entries, as follows:

1. The average CPU load for the previous minute. This value is 0.14 in the example below.
2. The average CPU load for the previous five minutes. This value is 0.10 in the example below.
3. The average CPU load for the previous ten minutes. This value is 0.08 in the example below.
4. The number of currently running processes and the total number of processes. The example below shows 1 of 68 processes running.
5. The last process ID used. This value is 11162 in the example below.

### User access

**admin, pseoperator**

### Syntax

**status cpu**

### Example

```
psesh:>status cpu
```

```
CPU Load Averages:
```

```
0.14 0.10 0.08 1/68 11162
```

```
System uptime:
```

```
At Fri Aug 5 07:26:15 EDT 2016, I am up 2:29
```

```
Command Result : 0 (Success)
```

## status date

---

Display the current date and time.

### User access

**admin, pseoperator**

### Syntax

**status date**

### Example

```
psesh:>status date
```

```
Fri Aug 5 07:29:04 EDT 2016
```

```
Command Result : 0 (Success)
```

## status disk

---

Display hard disk utilization.

### User access

admin, pseoperator

### Syntax

**status disk**

### Example

```
psesh:>status disk
```

```
===== Hard Disk utilization =====  
Filesystem      1K-blocks  Used Available Use% Mounted on  
/dev/sda2        3681872 696168   2795344  20% /  
/dev/sda1        194241  20086   163915  11% /boot
```

```
Command Result : 0 (Success)
```

---

## status interface

---

Display configuration and status information for the eth0 and eth1 interfaces.

### User access

admin, pseoperator

### Syntax

**status interface**

### Example

```
psesh:>status interface
```

```
eth0      Link encap:Ethernet  HWaddr 00:01:4E:02:D1:59
          inet addr:172.20.11.40  Bcast:172.20.11.255  Mask:255.255.255.0
          inet6 addr: fe80::201:4eff:fe02:d159/64  Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:20849 errors:0 dropped:0 overruns:0 frame:0
          TX packets:2183 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:2034969 (1.9 MiB)  TX bytes:291093 (284.2 KiB)
          Interrupt:16 Memory:fe9a0000-fe9c0000
```

```
eth1      Link encap:Ethernet  HWaddr 00:01:4E:02:D1:5A
          BROADCAST MULTICAST  MTU:1500  Metric:1
          RX packets:0 errors:0 dropped:0 overruns:0 frame:0
          TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:0 (0.0 b)  TX bytes:0 (0.0 b)
          Interrupt:17 Memory:feaa0000-feac0000
```

```
ETH0 (Speed|Duplex): 1000Mb/s|Full
```

```
ETH1 (Speed|Duplex): Unknown!|Unknown!
```

```
Command Result : 0 (Success)
```



## status mac

---

Display the MAC address of the eth0 and eth1 interfaces, if they have been configured.

### User access

**admin, pseoperator**

### Syntax

**status mac**

### Example

```
psesh:>status mac
```

```
eth0 00:01:4E:02:D1:59
```

```
Command Result : 0 (Success)
```

## status mem

---

Display the current memory usage.

### User access

**admin, pseoperator**

### Syntax

**status mem**

### Example

```
psesh:>status mem
```

	total	used	free	shared	buffers	cached
Mem:	1019668	127360	892308	164	6928	67688
-/+ buffers/cache:		52744	966924			
Swap:	0	0	0			

```
Command Result : 0 (Success)
```

## status netstat

Display the current network connections.

### User access

admin, pseoperator

### Syntax

**status netstat**

### Example

```
psesh:>status netstat
```

Active Internet connections (servers and established)

Proto	Recv-Q	Send-Q	Local Address	Foreign Address	State
tcp	0	0	0.0.0.0:22	0.0.0.0:*	LISTEN
tcp	0	0	172.20.11.40:22	10.124.0.34:52153	ESTABLISHED
tcp	0	0	:::12396	:::*	LISTEN
udp	0	0	0.0.0.0:68	0.0.0.0:*	

Active UNIX domain sockets (servers and established)

Proto	RefCnt	Flags	Type	State	I-Node	Path
unix	2	[ ACC ]	STREAM	LISTENING	8394	@/com/ubuntu/upstart
unix	2	[ ]	DGRAM		8828	@/org/kernel/udev/udev
unix	4	[ ]	DGRAM		12263	/dev/log
unix	2	[ ]	DGRAM		12661	
unix	2	[ ]	DGRAM		12266	
unix	2	[ ]	DGRAM		12109	
unix	2	[ ]	DGRAM		12055	
unix	2	[ ]	DGRAM		10517	
unix	3	[ ]	DGRAM		8845	
unix	3	[ ]	DGRAM		8844	

Command Result : 0 (Success)

## status ps

Display the status of all active processes.

### User access

admin, pseoperator

### Syntax

**status ps**

### Example

```
psesh:>status ps
```

USER	PID	%CPU	%MEM	VSZ	RSS	TTY	STAT	START	TIME	COMMAND
root	1	0.0	0.1	2900	1440	?	Ss	2020	0:07	/sbin/init
root	2	0.0	0.0	0	0	?	S	2020	0:00	[kthreadd]
root	3	0.0	0.0	0	0	?	S	2020	0:00	[migration/0]
root	4	0.0	0.0	0	0	?	S	2020	0:00	[ksoftirqd/0]
root	5	0.0	0.0	0	0	?	S	2020	0:00	[stopper/0]
root	6	0.0	0.0	0	0	?	S	2020	0:28	[watchdog/0]
root	11	0.0	0.0	0	0	?	S	2020	92:57	[events/0]
root	13	0.0	0.0	0	0	?	S	2020	0:00	[events/0]
root	15	0.0	0.0	0	0	?	S	2020	0:00	[events_long/0]
root	17	0.0	0.0	0	0	?	S	2020	0:00	[events_power_ef]
root	19	0.0	0.0	0	0	?	S	2020	0:00	[cgroup]
root	20	0.0	0.0	0	0	?	S	2020	0:00	[khelper]
root	21	0.0	0.0	0	0	?	S	2020	0:00	[netns]
root	22	0.0	0.0	0	0	?	S	2020	0:00	[async/mgr]
root	23	0.0	0.0	0	0	?	S	2020	0:00	[pm]
root	24	0.0	0.0	0	0	?	S	2020	0:19	[sync_supers]
root	25	0.0	0.0	0	0	?	S	2020	0:00	[bdi-default]
root	26	0.0	0.0	0	0	?	S	2020	0:00	[kintegrityd/0]
root	28	0.0	0.0	0	0	?	S	2020	0:02	[kblockd/0]
root	30	0.0	0.0	0	0	?	S	2020	0:00	[kacpid]
root	31	0.0	0.0	0	0	?	S	2020	0:00	[kacpi_notify]
root	32	0.0	0.0	0	0	?	S	2020	0:00	[kacpi_hotplug]
root	33	0.0	0.0	0	0	?	S	2020	0:00	[ata_aux]
root	34	0.0	0.0	0	0	?	S	2020	0:00	[ata_sff/0]
root	36	0.0	0.0	0	0	?	S	2020	0:00	[ksuspend_usbd]
root	37	0.0	0.0	0	0	?	S	2020	0:00	[khubd]
root	38	0.0	0.0	0	0	?	S	2020	0:00	[kseriod]
root	39	0.0	0.0	0	0	?	S	2020	0:00	[md/0]
root	41	0.0	0.0	0	0	?	S	2020	0:00	[md_misc/0]
root	43	0.0	0.0	0	0	?	S	2020	0:00	[linkwatch]
root	44	0.0	0.0	0	0	?	S	2020	0:02	[khungtaskd]
root	45	0.0	0.0	0	0	?	S	2020	0:00	[lru-add-drain/0]
root	47	0.0	0.0	0	0	?	S	2020	0:00	[kswapd0]
root	48	0.0	0.0	0	0	?	SN	2020	0:00	[ksmd]
root	49	0.0	0.0	0	0	?	S	2020	0:00	[aio/0]
root	51	0.0	0.0	0	0	?	S	2020	0:00	[crypto/0]
root	59	0.0	0.0	0	0	?	S	2020	0:00	[kthrotld/0]
root	62	0.0	0.0	0	0	?	S	2020	0:00	[kpsmoused]
root	63	0.0	0.0	0	0	?	S	2020	0:00	[usbhid_resumer]

```

root      64  0.0  0.0      0    0 ?      S      2020  0:00 [deferwq]
root     276  0.0  0.0      0    0 ?      S      2020  0:00 [scsi_eh_0]
root     277  0.0  0.0      0    0 ?      S      2020  0:00 [scsi_eh_1]
root     280  0.0  0.0      0    0 ?      S      2020  0:00 [scsi_eh_2]
root     281  0.0  0.0      0    0 ?      S      2020  0:00 [scsi_eh_3]
root     317  0.0  0.0      0    0 ?      S      2020  0:03 [jbd2/sda2-8]
root     318  0.0  0.0      0    0 ?      S      2020  0:00 [ext4-dio-unwrit]
root     404  0.0  0.0    2700  980 ?    S<s    2020  0:00 /sbin/udev -d
root     650  0.0  0.0      0    0 ?      S      2020  0:00 [kdmremove]
root     651  0.0  0.0      0    0 ?      S      2020  0:00 [kstripped]
root     676  0.0  0.0      0    0 ?      S      2020  0:00 [jbd2/sda1-8]
root     677  0.0  0.0      0    0 ?      S      2020  0:00 [ext4-dio-unwrit]
root     712  0.0  0.0      0    0 ?      S      2020  0:00 [kauditd]
root     943  0.0  0.0    2836  776 ?    Ss     2020  0:02 /sbin/dhclient -H PSe-II -l -q
-lf /var/lib/dhclient/dhclient-eth0.
root    1039  0.0  0.0   13932  864 ?    S<sl   2020  0:09 auditd
root    1059  0.0  0.2   36224  2240 ?    Sl     2020  0:02 /sbin/rsyslogd -i
/var/run/syslogd.pid -c 5
root    1095  0.0  0.3   19140  3516 ?    S      2020  57:20 /usr/sbin/snmpd -LS0-6d -Lf
/dev/null -p /var/run/snmpd.pid
root    1111  0.0  0.0      0    0 ?      S      2020  0:00 [viper0_sm]
root    1138  0.0  0.1    9024  1084 ?    Ss     2020  0:00 /usr/sbin/sshd
root    1148  0.0  0.1    6036  1312 ?    Ss     2020  0:29 crond
root    1160  0.0  0.0  155864  712 ?    Sl     2020  0:45 /usr/bin/etnetserver -d
root    1192  0.0  0.0    3024  504 ?    Ss     2020  0:00 /usr/sbin/atd
root    1262  0.0  0.0    2124  576 ?      S      2020  0:00 audittrace
root    1280  0.0  0.0    2008  516 tty1    Ss+    2020  0:00 /sbin/mingetty /dev/tty1
root    1282  0.0  0.0    2008  520 tty2    Ss+    2020  0:00 /sbin/mingetty /dev/tty2
root    1284  0.0  0.0    2008  516 tty3    Ss+    2020  0:00 /sbin/mingetty /dev/tty3
root    1286  0.0  0.0    2008  520 tty4    Ss+    2020  0:00 /sbin/mingetty /dev/tty4
root    1291  0.0  0.0    2008  520 tty5    Ss+    2020  0:00 /sbin/mingetty /dev/tty5
root    1295  0.0  0.0    2008  512 tty6    Ss+    2020  0:00 /sbin/mingetty /dev/tty6
root    1296  0.0  0.1    3356  1800 ?    S<     2020  0:00 /sbin/udev -d
root    1297  0.0  0.1    3356  1788 ?    S<     2020  0:00 /sbin/udev -d
root    1438  0.0  0.0    2020   528 ttyS0   Ss+    2020  0:00 /sbin/agetty -L 115200 ttyS0
vt102
root   29014  0.0  0.3   12112  3840 ?    Ss     11:41  0:02 sshd: admin@pts/0
root   29019  0.0  0.0    2300   920 pts/0   Ss+    11:41  0:00 -pssh
root   29147  0.0  0.0      0     0 ?      S      15:41  0:00 [flush-8:0]
root   29148  0.0  0.1    2988  1088 pts/0   S+     15:43  0:00 /bin/sh S
root   29149  15.0  0.0    2852   960 pts/0   R+     15:43  0:00 ps auxw

```

Command Result : 0 (Success)

## status time

---

Display the time currently configured on the appliance, using the 24 hour clock.

### User access

**admin, pseoperator**

### Syntax

**status time**

### Example

```
psesh:>status time
```

```
07:31:41
```

```
Command Result : 0 (Success)
```

## status zone

---

Display the currently configured time zone.

### User access

**admin, pseoperator**

### Syntax

**status zone**

### Example

```
psesh:>status zone
```

```
EDT
```

```
Command Result : 0 (Success)
```

## sysconf

Configure the appliance time, date, or SNMP settings, or reboot or power-off the appliance.

### User access

admin, pseoperator

### Syntax

#### sysconf

appliance  
etnetcfg  
snmp  
time  
timezone

Argument(s)	Shortcut	Description
appliance	a	Reboot or power-off the appliance. See <a href="#">"sysconf appliance" on the next page</a> .
etnetcfg	e	View or change the configuration file used to determine HSM appliance server settings. See <a href="#">"sysconf etnetcfg" on page 109</a> .
snmp	s	Configure the SNMP settings on the appliance. See <a href="#">"sysconf snmp" on page 112</a> .
time	t	Set the appliance time and date. See <a href="#">"sysconf time" on page 117</a> .
timezone	timez	Display or set the appliance timezone. See <a href="#">"sysconf timezone" on page 118</a> .



## sysconf appliance

Reboot or power-off the appliance, or reset appliance account passwords and configuration settings to factory defaults.

### User Access

admin, pseoperator

### Syntax

#### sysconf appliance

factory  
poweroff  
reboot

Argument(s)	Shortcut	Description
factory	f	Reset all appliance account passwords, SNMP, and network configuration to factory settings. See <a href="#">"sysconf appliance factory" on the next page</a> .
poweroff	p	Power-off the appliance. See <a href="#">"sysconf appliance poweroff" on page 107</a> .
reboot	r	Reboot the appliance. See <a href="#">"sysconf appliance reboot" on page 108</a> .

---

## sysconf appliance factory

---

Reset all appliance account passwords, SNMP, and network configuration to factory settings.

### User Access

**admin**

### Syntax

**sysconf appliance factory**

### Example

```
psesh:>sysconf appliance factory
```

```
WARNING !! This command will reset the appliance to factory defaults.  
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'
```

```
> proceed  
Proceeding...  
Changing password for user admin.  
passwd: all authentication tokens updated successfully.  
Changing password for user audit.  
passwd: all authentication tokens updated successfully.  
Changing password for user pseoperator.  
passwd: all authentication tokens updated successfully.  
Shutting down interface eth0: [ OK ]  
Shutting down interface eth1: [ OK ]  
Shutting down loopback interface: [ OK ]  
Bringing up loopback interface: [ OK ]  
Bringing up interface eth0: Determining if ip address 172.20.9.35 is already in use for device  
eth0...  
[ OK ]  
Bringing up interface eth1: Determining if ip address 192.168.1.100 is already in use for  
device eth1...  
[ OK ]
```

```
Command Result : 0 (Success)
```

---

## sysconf appliance poweroff

---

Power-off the appliance.

### User Access

**admin, pseoperator**

### Syntax

**sysconf appliance poweroff**

### Example

```
psesh:>sysconf appliance poweroff
```

```
WARNING !! This command will power off the appliance.
```

```
    All clients will be disconnected and the appliance will require a manual power on  
for further access.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'
```

```
> proceed
```

```
Proceeding...
```

```
Broadcast message from root@PSE-II  
    (/dev/pts/0) at 7:58 ...
```

```
The system is going down for power off NOW!  
Power off commencing
```

```
It is now safe to poweroff the appliance.
```

```
Command Result : 0 (Success)
```

---

## sysconf appliance reboot

---

Reboot the appliance.

### User Access

**admin, pseoperator**

### Syntax

**sysconf appliance reboot**

### Example

```
psesh:>sysconf appliance reboot
```

```
WARNING !! This command will reboot the appliance.  
All clients will be disconnected.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'
```

```
> proceed  
Proceeding...
```

```
Broadcast message from root@PSE-II  
(/dev/pts/0) at 7:55 ...
```

```
The system is going down for reboot NOW!  
Reboot commencing
```

```
Command Result : 0 (Success)
```

## sysconf etnetcfg

View or change the configuration file used to determine HSM appliance server settings.

### User Access

admin, pseoperator

### Syntax

#### sysconf etnetcfg

**set**  
**show**

Argument(s)	Shortcut	Description
<b>set</b>	<b>se</b>	Use the specified configuration file as the basis for HSM appliance server settings. See <a href="#">"sysconf etnetcfg set" on the next page</a> .
<b>show</b>	<b>sh</b>	View the current etnetserver configuration settings. See <a href="#">"sysconf etnetcfg show" on page 111</a> .

## sysconf etnetcfg set

Use the specified configuration file as the basis for HSM appliance server settings. This file must be transferred to the appliance using **scp/pscp**.

### User Access

**admin, pseoperator**

### Syntax

**sysconf etnetcfg set** <filename>

Argument(s)	Shortcut	Description
<filename>		Specifies the configuration file to be used as the basis for HSM appliance server settings.

### Example

```
psesh:>sysconf etnetcfg set et_hsm.txt
```

```
WARNING !! This command will modify the settings of the appliance.
            It could affect client connections, and result in an unusable system.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'

> proceed
Proceeding...
The config file has been set. To apply the changes, please restart etnetserver
```

```
Command Result : 0 (Success)
```

---

## sysconf etnetcfg show

---

View the current etnetserver configuration settings.

### User Access

**admin, pseoperator**

### Syntax

**sysconf etnetcfg show**

### Example

```
psesh:>sysconf etnetcfg show
```

```
etnetserver is running
```

```
Current etnetserver configuration
```

```
ET_HSM_NETSERVER_OLD_WORKER_COUNT=5  
ET_HSM_NETSERVER_V2_WORKER_COUNT=12  
ET_HSM_NETSERVER_READ_TIMEOUT_SECS=40  
ET_HSM_NETSERVER_WRITE_TIMEOUT_SECS=40  
ET_HSM_NETSERVER_CONN_TIMEOUT_COUNT=5  
ET_HSM_NETSERVER_FRAG_SIZE=5000  
ET_HSM_NETSERVER_ALLOW_RESET=OnHalt  
ET_HSM_NETSERVER_PORT=12396  
ET_HSM_NETSERVER_LOG_CHANNEL=0  
ET_HSM_NETSERVER_LOG_NAME=etnetserver  
ET_HSM_NETSERVER_LOG_LEVEL=0
```

```
Command Result : 0 (Success)
```

## sysconf snmp

Enable or disable the SNMP service, or display or configure the SNMP settings for the appliance.

### User Access

admin

### Syntax

**sysconf snmp**

**config**  
**disable**  
**enable**  
**show**

Argument(s)	Shortcut	Description
<b>config</b>	<b>c</b>	Configure the SNMP settings for the appliance. See " <a href="#">sysconf snmp config</a> " on the next page.
<b>disable</b>	<b>d</b>	Disable SNMP on the appliance and stop the SNMP service. See " <a href="#">sysconf snmp disable</a> " on page 114.
<b>enable</b>	<b>e</b>	Enable SNMP on the appliance and start the SNMP service. See " <a href="#">sysconf snmp enable</a> " on page 115.
<b>show</b>	<b>s</b>	Display the current SNMP settings for the appliance. See " <a href="#">sysconf snmp show</a> " on page 116.



## sysconf snmp config

Configure the SNMP server on the appliance.

### User Access

admin

### Syntax

**sysconf snmp config -contact <string> -location <string> -ip <IP\_address> -community <string>**

Argument(s)	Shortcut	Description
<b>-community</b> <string>	<b>-com</b>	Specifies the community string for the SNMP server on the appliance. SNMP community strings function as passwords that are embedded in every SNMP packet to authenticate access to the Management Information Base (MIB) on the appliance. Enter this keyword followed by the community string.
<b>-contact</b> <string>	<b>-con</b>	Specifies the contact information for the SNMP server on the appliance. Enter this keyword followed by the contact information string. Enclose the string in quotes if it contains spaces.
<b>-ip</b> <IP_address>	<b>-i</b>	Specifies the IP address of the SNMP trap destination. Enter this keyword followed by the IP address of the host used to accept SNMP traps that originate on the appliance.
<b>-location</b> <string>	<b>-l</b>	Specifies the location of the SNMP server on the appliance. Enter this keyword followed by the location string. Enclose the string in quotes if it contains spaces.

### Example

```
psesh:>sysconf snmp config -contact testcontact -location testlocation -ip 10.124.93.19 -
community testcommunity
```

Command Result : 0 (Success)

## sysconf snmp disable

---

Disable SNMP on the appliance and stop the SNMP service.

### User Access

**admin**

### Syntax

**sysconf snmp disable**

### Example

```
psesh:>sysconf snmp disable
```

```
SNMP is disabled
```

```
Stopping snmpd:
```

```
SNMP is stopped
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

## sysconf snmp enable

---

Enable SNMP on the appliance and start the SNMP service.

### User Access

**admin**

### Syntax

**sysconf snmp enable**

### Example

```
psesh:>sysconf snmp enable
```

```
SNMP is enabled
```

```
Starting snmpd:
```

```
SNMP is started
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

## sysconf snmp show

Display the current SNMP settings for the appliance.

### User Access

admin

### Syntax

**sysconf snmp show**

### Example

```
psesh:>sysconf snmp show
```

```
SNMP is running
```

```
SNMP is enabled
```

```
Current SNMP configuration
```

```
#####
#          ProtectServer SNMP v2c snmpd.conf          #
#####
agentuser root
syslocation TESTLAB
syscontact TESTCONTACT
com2sec secName 192.168.11.17 COMMUNITY
group secNameGroup v2c secName
view systemview included .1.3.6.1.2.1.1
view systemview included .1.3.6.1.2.1.2
view systemview included .1.3.6.1.2.1.25.1
view systemview included .1.3.6.1.2.1.25.2
view systemview included .1.3.6.1.2.1.25.3
view systemview included .1.3.6.1.2.1.25.4
access secNameGroup "" any noauth exact systemview none none
```

```
Command Result : 0 (Success)
```

## sysconf time

Set the time and date on the appliance.

### User Access

admin

### Syntax

**sysconf time** <time> <date>

Argument(s)	Shortcut	Description
<time>		Set the time on the appliance. Time must be specified in 24-hour format (HH:MM).
<date>		Set the date on the appliance (YYYYMMDD).

### Example

```
psesh:>sysconf time 09:41 20191202
```

```
Mon Dec 2 09:41:00 EST 2019
```

```
Command Result : 0 (Success)
```

## sysconf timezone

Display or set the timezone on the appliance.

### User Access

admin, pseoperator

### Syntax

#### sysconf timezone

set  
show

Argument(s)	Shortcut	Description
set	se	Set the time zone on the appliance. See " <a href="#">sysconf timezone set</a> " on the next page.
show	sh	Display the currently configured time zone. See " <a href="#">sysconf timezone show</a> " on page 120.

## sysconf timezone set

Set the time zone on the appliance. The appliance uses the Linux standard for specifying the time zone. This standard provides several different methods for specifying the time zone. For example, if you are located in Toronto, Canada, you could specify the time zone as EST, Canada/Eastern, America/Toronto, or GMT-5.

### User Access

admin

### Syntax

**sysconf timezone set** <timezone>

Argument(s)	Shortcut	Description
<timezone>		Specifies the time zone on the appliance. For a list of valid time zones, refer to the <b>/usr/share/zoneinfo</b> directory on any Redhat distribution.

### Example

```
psesh:>sysconf timezone set Canada/Eastern
```

```
Timezone set to Canada/Eastern  
Command Result : 0 (Success)
```

## sysconf timezone show

---

Display the currently configured time zone.

### User Access

**admin, pseoperator**

### Syntax

**sysconf timezone show**

### Example

```
psesh:>sysconf timezone show
```

```
EDT
```

```
Command Result : 0 (Success)
```



# syslog

Manage system logs, and configure automatic log-keeping behavior.

## User access

admin, pseoperator

## Syntax

### syslog

cleanup  
export  
period  
remotehost  
rotate  
rotations  
show  
tail  
tarlogs

Argument(s)	Shortcut	Description
cleanup	c	Create an archive of the current logs and then delete all log files. See <a href="#">"syslog cleanup" on page 123</a> .
export	e	Export syslog to file for transfer from appliance. See <a href="#">"syslog export" on page 124</a> .
period	p	Sets the time between syslog rotations. See <a href="#">"syslog period" on page 125</a> .
remotehost	re	Configures syslog to send logs to remote hosts. See <a href="#">"syslog remotehost" on page 126</a> .
rotate	rotate	Rotates log files immediately, if they have not already been rotated on the same date. Logs cannot be rotated more than once per day. See <a href="#">"syslog rotate" on page 131</a> .
rotations	rotati	Sets the number of old syslogs that are kept. See <a href="#">"syslog rotations" on page 132</a> .
show	s	Display the current log rotation configuration and the configured log levels. See <a href="#">"syslog show" on page 133</a> .
tail	tai	Display the last entries of the specified syslog. See <a href="#">"syslog tail" on page 135</a> .

---

Argument(s)	Shortcut	Description
<b>tarlogs</b>	<b>tar</b>	Create an archive of the syslog. See " <a href="#">syslog tarlogs</a> " on <a href="#">page 136</a> .

---

## syslog cleanup

---

Creates a .tar archive of logs currently on the HSM, and deletes all log files. The resulting archive is saved to the appliance SCP directory for transfer, named "**logs\_cleanup\_YYYYMMDD\_hhmm.tgz**".

### User Access

**admin**

### Syntax

**syslog cleanup**

### Example

```
psesh:>syslog cleanup
```

```
WARNING !! This command creates an archive of the current logs and then DELETES ALL THE LOG FILES.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
```

```
Proceeding...
```

```
Creating tarlogs then deleting all log files ...
```

```
The tar file containing logs is now available via scp as filename "logs_cleanup_20191105_1607.tgz".
```

```
Please copy "logs_cleanup_20191105_1607.tgz" to a client machine with scp.
```

```
Deleting log files ...
```

```
restart the rsyslogd service if it's running
```

```
Command Result : 0 (Success)
```

## syslog export

---

Prepare system logs for transfer from appliance. This command copies the current system log file to the export directory so that the user can use **scp** to transfer the file to another computer. Can be used for offline storage of old log files or to send to Technical Support for troubleshooting the ProtectServer appliance.

### User Access

**admin**

### Syntax

**syslog export**

### Example

```
psesh:>syslog export
```

```
System log files successfully prepared for secure transfer.  
Use scp from a client machine to get the file named: "syslog"
```

```
Command Result : 0 (Success)
```

## syslog period

---

Set the time between syslog rotations.

### User Access

admin

### Syntax

**syslog period** <syslogperiod>

Argument(s)	Description
<syslogperiod>	Specifies the log rotation period. <b>Valid values:</b> daily, weekly, monthly

### Example

```
psesh:>syslog period daily
```

```
Log period set to daily.
```

```
Command Result : 0 (Success)
```

## syslog remotehost

Access the **syslog remotehost** commands to manage the syslog remote hosts.

### User Access

admin

### Syntax

#### syslog remotehost

add  
clear  
delete  
list

Argument(s)	Shortcut	Description
add	a	Add a remote host. See <a href="#">"syslog remotehost add" on the next page</a> .
clear	c	Delete All Remote Logging Servers. See <a href="#">"syslog remotehost clear" on page 128</a> .
delete	d	Delete a remote host. See <a href="#">"syslog remotehost delete" on page 129</a> .
list	l	List all syslog remote hosts. See <a href="#">"syslog remotehost list" on page 130</a> .

## syslog remotehost add

Add a remote host receiving the logs. Can be any system that provides the remote syslog service.

**NOTE** For this function to work you must open receiving udp port 514 on the remote log server.

### User Access

admin

### Syntax

**syslog remotehost add** <hostname/IP>

Argument(s)	Description
<hostname/IP>	Specifies the hostname or the IP address of the remote computer system that will be accepting and storing the syslogs.

### Example

```
psesh:>syslog remotehost add mylinuxbox
```

```
mylinuxbox added successfully
```

```
Please restart syslog with <service restart syslog> command
```

```
Make sure syslog service is started on mylinuxbox with -r option
```

```
Command Result : 0 (Success)
```

## syslog remotehost clear

Delete all remote logging servers.

### User Access

admin

### Syntax

**syslog remotehost clear [-force]**

Argument(s)	Shortcut	Description
<b>-force</b>	<b>-f</b>	Force the action; useful for scripting.

### Example

```
psesh:>syslog remotehost clear
```

```

All remote hosts receiving the logs will be deleted.
Are you sure you wish to continue?

```

```
Type proceed to continue, or quit to quit now -> proceed
```

```

Shutting down kernel logger:          [ OK ]
Shutting down system logger:         [ OK ]
Starting system logger:               [ OK ]
Starting kernel logger:               [ OK ]

```

```
Command Result : 0 (Success)
```



## syslog remotehost delete

Delete a remote host receiving the logs. Use **syslog remotehost list** to see which systems are receiving the logs.

### User Access

admin

### Syntax

**syslog remotehost delete** <hostname/IP>

Argument(s)	Description
<hostname/IP>	Specifies the hostname or the IP address of the remote computer system to delete from the list.

### Example

```
psesh:>syslog remotehost delete mylinuxbox
```

```
mylinuxbox deleted successfully
```

```
Please restart syslog with <service restart syslog> command  
to stop logs to be sent to mylinuxbox
```

```
Command Result : 0 (Success)
```

## syslog remotehost list

---

List the syslog remote hosts.

### User Access

**admin**

### Syntax

**syslog remotehost list**

### Example

```
psesh:>syslog remotehost list
```

```
List of syslog remote hosts:  
mylinuxbox
```

```
Command Result : 0 (Success)
```

## syslog rotate

---

Rotate log files immediately, if they have not already been rotated on the same date. Logs cannot be rotated more than once per day.

**NOTE** Using this command followed by **syslog cleanup** causes all growable log files to be deleted.

### User Access

admin

### Syntax

**syslog rotate**

### Example

```
lunash:>syslog rotate
```

Command Result : 0 (Success)

## syslog rotations

Set the number of history files to keep when rotating system log files. For example, two rotations would keep the current log files and the most recent set; three rotations would keep the current log files and the two most recent sets. Specify a whole number less than 100.

### User Access

admin

### Syntax

**syslog rotations** <syslog\_rotations>

Argument(s)	Description
<syslog_rotations>	An integer that specifies the number of history files to keep when rotating system log files. <b>Range:</b> 1 to 100

### Example

```
psesh:> syslog rotations 5
```

```
Log rotations set to 5
```

```
Command Result : 0 (Success)
```

## syslog show

Display the current log rotation configuration, and show the configured log levels. Optionally show a list of the log files.

### User Access

admin, pseoperator

### Syntax

**syslog show [-files]**

Argument(s)	Shortcut	Description
<b>-files</b>	<b>-f</b>	Binary option. If this option is present, a list of all log files is presented. If this option is absent, then a summary of log configuration is shown, without the file list.

### Example

```
psesh:>syslog show -files
```

Syslog configuration

```
Rotations:          4
Rotation Period:    weekly
```

Configured Log Levels:

-----

```
syslog:
cron:      *                               /var/log/cron
boot:      *                               /var/log/boot
```

Note: '\*' means all log levels.

```
LogFileName          Size Date Time
-----
anaconda.ifcfg.log   4550 Aug 5 09:49
anaconda.log         20753 Aug 5 09:49
anaconda.program.log 38069 Aug 5 09:49
anaconda.storage.log 102111 Aug 5 09:49
anaconda.syslog      78833 Aug 5 09:49
anaconda.yum.log     25369 Aug 5 09:49
audit                4096 Aug 5 09:53
boot.log             1870 Aug 5 10:44
btmpt                768 Aug 5 09:54
cron                 1445 Aug 5 10:50
dmesg                44346 Aug 5 09:52
dracut.log           149964 Aug 5 09:49
lastlog              146000 Aug 5 10:36
```

```
maillog          191 Aug 5 09:53
messages        59317 Aug 5 11:00
secure          2858 Aug 5 10:37
spooler         0 Aug 5 09:43
tallylog        0 Aug 5 09:42
wtmp            11904 Aug 5 10:37
```

Command Result : 0 (Success)

## syslog tail

Display the last entries of the syslog. If no number is included, the command displays the entire syslog.

### User access

admin, pseoperator

### Syntax

**syslog tail -logname** <logname> [-entries <logentries>] [-search <string>]

Argument(s)	Shortcut	Description
<b>-entries</b> <logentries>	<b>-e</b>	Specifies the number of entries to display. If this parameter is not specified, the entire log is displayed. Enter this keyword followed by the number of log entries you want to display. <b>Range:</b> 0-2147483647
<b>-logname</b> <logname>	<b>-l</b>	Species the name of the log you want to display. Enter this keyword followed by the log name. <b>Valid values:</b> messages, secure
<b>-search</b> <string>	<b>-s</b>	Search the log for the specified string. Enter this keyword followed by the string you want to find.

### Example

```
psesh:>syslog tail -logname messages -entries 10
```

```
Aug  5 12:00:17 PSe-II snmpd[3963]: Connection from UDP: [172.16.21.19]:62386->[172.20.11.150]
Aug  5 12:00:18 PSe-II snmpd[3963]: Connection from UDP: [172.16.21.19]:62386->[172.20.11.150]
Aug  5 12:04:16 PSe-II psesh [4341]: info : 0 : pssh user login : admin : 172.16.181.182/51177
Aug  5 12:04:28 PSe-II psesh [4341]: info : 0 : Command: help syslog : admin :
172.16.181.182/51177
Aug  5 12:06:36 PSe-II psesh [4341]: info : 0 : Command: help syslog tar : admin :
172.16.181.182/51177
Aug  5 12:07:32 PSe-II psesh [4341]: info : 0 : Command: syslog tail : admin :
172.16.181.182/51177
Aug  5 12:09:55 PSe-II psesh [4341]: info : 0 : Command: syslog tarlogs : admin :
172.16.181.182/51177
Aug  5 12:09:57 PSe-II rsyslogd: [origin software="rsyslogd" swVersion="5.8.10" x-pid="927" x-
info="http://www.rsyslog.com"] rsyslogd was HUPed
Aug  5 12:14:59 PSe-II psesh [4341]: info : 0 : Command: syslog tail -logname messages -entries
10 : admin : 172.16.181.182/51177
Aug  5 12:15:16 PSe-II psesh [4341]: info : 0 : Command: syslog tail -logname messages -entries
10 : admin : 172.16.181.182/51177
```

Command Result : 0 (Success)

## syslog tarlogs

---

Create an archive of the syslog.

### User access

**admin, pseoperator, audit**

### Syntax

**syslog tarlogs**

### Example

```
psesh:>syslog tarlogs
```

```
Generating package list...
```

```
Generating tarlogs...
```

```
The tar file containing logs is now available via scp as filename 'pselogs.tgz'.
```

```
Command Result : 0 (Success)
```



## user password

Set or change the password for the current user. Although there are no restrictions on the password you can use, warnings are displayed if the password is short, simple, or uses a dictionary word.

The **admin** user can also use the **-user** parameter to change the password for the **pseoperator** or **audit** user.

### User access

**admin, pseoperator, audit**

### Syntax

**user password [-user <username>]**

Argument(s)	Shortcut	Description
<b>-user &lt;username&gt;</b>	<b>-u</b>	Specifies the user name of the user whose password you want to change. This parameter can only be used by the <b>admin</b> user.

### Example

```
psesh:>user password
```

Changing password for user admin.

New password:

BAD PASSWORD: it is too short

BAD PASSWORD: is too simple

Retype new password:

Sorry, passwords do not match.

New password:

BAD PASSWORD: it is too short

BAD PASSWORD: is too simple

Retype new password:

passwd: all authentication tokens updated successfully.

Command Result : 0 (Success)

```
psesh:>user password
```

Changing password for user admin.

New password:

BAD PASSWORD: it is based on a dictionary word

Retype new password:

passwd: all authentication tokens updated successfully.

Command Result : 0 (Success)

```
psesh:>user password -user pseoperator
```

```
Changing password for user pseoperator.
```

```
New password:
```

```
Retype new password:
```

```
passwd: all authentication tokens updated successfully.
```

```
Command Result : 0 (Success)
```

---

# Glossary

---

## A

---

### Adapter

The printed circuit board responsible for cryptographic processing in a HSM

### AES

Advanced Encryption Standard

### API

Application Programming Interface

### ASO

Administration Security Officer

### Asymmetric Cipher

An encryption algorithm that uses different keys for encryption and decryption. These ciphers are usually also known as public-key ciphers as one of the keys is generally public and the other is private. RSA and ElGamal are two asymmetric algorithms

## B

---

### Block Cipher

A cipher that processes input in a fixed block size greater than 8 bits. A common block size is 64 bits

### Bus

One of the sets of conductors (wires, PCB tracks or connections) in an IC

## C

---

### CA

Certification Authority

### CAST

Encryption algorithm developed by Carlisle Adams and Stafford Tavares

### Certificate

A binding of an identity (individual, group, etc.) to a public key which is generally signed by another identity. A certificate chain is a list of certificates that indicates a chain of trust, i.e. the second certificate has signed the first, the

third has signed the second and so on

## CMOS

Complementary Metal-Oxide Semiconductor. A common data storage component

## Cprov

ProtectToolkit C - SafeNet's PKCS #11 Cryptoki Provider

## Cryptoki

Cryptographic Token Interface Standard. (aka PKCS#11)

## CSA

Cryptographic Services Adapter

## CSPs

Microsoft Cryptographic Service Providers

# D

---

## Decryption

The process of recovering the plaintext from the ciphertext

## DES

Cryptographic algorithm named as the Data Encryption Standard

## Digital Signature

A mechanism that allows a recipient or third party to verify the originator of a document and to ensure that the document has not be altered in transit

## DLL

Dynamically Linked Library. A library which is linked to application programs when they are loaded or run rather than as the final phase of compilation

## DSA

Digital Signature Algorithm

# E

---

## Encryption

The process of converting the plaintext data into the ciphertext so that the content of the data is no longer obvious. Some algorithms perform this function in such a way that there is no known mechanism, other than decryption with the appropriate key, to recover the plaintext. With other algorithms there are known flaws which reduce the difficulty in recovering the plaintext

## F

---

### FIPS

Federal Information Protection Standards

### FM

Functionality Module. A segment of custom program code operating inside the CSA800 HSM to provide additional or changed functionality of the hardware

### FMSW

Functionality Module Dispatch Switcher

## H

---

### HA

High Availability

### HIFACE

Host Interface. It is used to communicate with the host system

### HSM

Hardware Security Module

## I

---

### IDEA

International Data Encryption Algorithm

### IIS

Microsoft Internet Information Services

### IP

Internet Protocol

## J

---

### JCA

Java Cryptography Architecture

## JCE

Java Cryptography Extension

## K

---

### Keyset

A keyset is the definition given to an allocated memory space on the HSM. It contains the key information for a specific user

### KWRAP

Key Wrapping Key

## M

---

### MAC

Message authentication code. A mechanism that allows a recipient of a message to determine if a message has been tampered with. Broadly there are two types of MAC algorithms, one is based on symmetric encryption algorithms and the second is based on Message Digest algorithms. This second class of MAC algorithms are known as HMAC algorithms. A DES based MAC is defined in FIPS PUB 113, see <http://www.itl.nist.gov/div897/pubs/fip113.htm>. For information on HMAC algorithms see RFC-2104 at <http://www.ietf.org/rfc/rfc2104.txt>

### Message Digest

A condensed representation of a data stream. A message digest will convert an arbitrary data stream into a fixed size output. This output will always be the same for the same input stream however the input cannot be reconstructed from the digest

### MSCAPI

Microsoft Cryptographic API

### MSDN

Microsoft Developer Network

## P

---

### Padding

A mechanism for extending the input data so that it is of the required size for a block cipher. The PKCS documents contain details on the most common padding mechanisms of PKCS#1 and PKCS#5

### PCI

Peripheral Component Interconnect

**PEM**

Privacy Enhanced Mail

**PIN**

Personal Identification Number

**PKCS**

Public Key Cryptographic Standard. A set of standards developed by RSA Laboratories for Public Key Cryptographic processing

**PKCS #11**

Cryptographic Token Interface Standard developed by RSA Laboratories

**PKI**

Public Key Infrastructure

**ProtectServer**

SafeNet HSM

**ProtectToolkit C**

SafeNet's implementation of PKCS#11. Protecttoolkit C represents a suite of products including various PKCS#11 runtimes including software only, hardware adapter, and host security module based variants. A Remote client and server are also available

**ProtectToolkit J**

SafeNet's implementation of JCE. Runs on top of ProtectToolkit C

---

**R****RC2/RC4**

Ciphers designed by RSA Data Security, Inc.

**RFC**

Request for Comments, proposed specifications for various protocols and algorithms archived by the Internet Engineering Task Force (IETF), see <http://www.ietf.org>

**RNG**

Random Number Generator

**RSA**

Cryptographic algorithm by Ron Rivest, Adi Shamir and Leonard Adelman

## RTC

Real-Time Clock

## S

---

### SDK

Software Development Kits Other documentation may refer to the SafeNet Cprov and Protect Toolkit J SDKs. These SDKs have been renamed ProtectToolkit C and ProtectToolkit J respectively. ⌚ The names Cprov and ProtectToolkit C refer to the same device in the context of this or previous manuals. ⌚ The names Protect Toolkit J and ProtectToolkit J refer to the same device in the context of this or previous manuals.

### Slot

PKCS#11 slot which is capable of holding a token

### SlotPKCS#11

Slot which is capable of holding a token

### SO

Security Officer

### Symmetric Cipher

An encryption algorithm that uses the same key for encryption and decryption. DES, RC4 and IDEA are all symmetric algorithms

## T

---

### TC

Trusted Channel

### TCP/IP

Transmission Control Protocol / Internet Protocol

### Token

PKCS#11 token that provides cryptographic services and access controlled secure key storage

### TokenPKCS#11

Token that provides cryptographic services and access controlled secure key storage



## U

---

### URI

Universal Resource Identifier

## V

---

### VA

Validation Authority

## X

---

### X.509

Digital Certificate Standard

#### X.509 Certificate

Section 3.3.3 of X.509v3 defines a certificate as: "user certificate; public key certificate; certificate: The public keys of a user, together with some other information, rendered unforgeable by encipherment with the private key of the certification authority which issued it"